


















Originalfernbedienung    Ersatzfernbedienung

	Power		Power
	Mute		Mute
	V.Format		Format
	Sleep		Sleep
	FAV		Pre Ch
	Tv/♪		TV/R
	AV		AV
	SAT		Media
	Zoom		Eject
	Camera		Smart
	Vol+		Vol +
	Vol-		Vol -
	CH+		Ch +
	CH-		Ch -
	Info		Info
	Back		Back
	Menu		Menu

Originalfernbedienung    Ersatzfernbedienung

	[≡]		Text
	Guide		Guide
	Exit		Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	↑		Shift + Up
	↓		Shift + Down
	Red		Red
	Green		Green
	Yellow/Audio		Yellow
	Blue/[...]		Blue
	1		1
	2		2
	3		3



