

























































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Tv/Rad.		TV/R
	Subtitle		Subt
	AD		Shift + Subt
	[↔]/Ratio		3D
	Ext(Cable)		AV
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	List		List

Originalfernbedienung Ersatzfernbedienung

	Q.View		Media
	FAV		Pre Ch
	Guide		Guide
	Mute		Mute
	Vol+		Vol +
	Vol-		Vol -
	PR+		Ch +
	PR-		Ch -
	Text		Text
	Home		Smart
	*		Menu
	T.Opt.		Options
	Q.Menu		D. Menu
	Up		Up
	Down		Down
	Right		Right
	Left		Left



