



Originalfernbedienung Ersatzfernbedienung

	Digital		Display / Media
	Yellow/Theater Modes/Info		Yellow / YouTube / Repeat
	Power		Power
	Tv		Shift + 1
	DVD		Shift + 2
	Green/Stereo/[...]		Green / APP / Repeat
	Blue/Delay/Title		Blue / Prime Video / Random
	Red/Center/Audio		Red / Netflix / Search
	Up		Up
	Violet/Level/Came		Fav / Marker / PC
	Tape		Shift + 5
	SAT/CAB		Shift + 0
	Tuner		Shift + 6
	Video/VCR		Shift + 4
	Left/-		Left
	OK		OK
	Right/+		Right

Originalfernbedienung Ersatzfernbedienung

	PTY		Text / Goto
	Down		Down
	Menu/RDS		Menu / Home
	Vol+		Vol+
	PR+ />>I		CH+ / Page+
	Vol-		Vol-
	PR- /I<<		CH- / Page-
	Mute		Mute / Dimmer
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9





Originalfernbedienung Ersatzfernbedienung




























	Memo / Clear		Smart / List
	0		0

Originalfernbedienung Ersatzfernbedienung







































Originalfernbedienung Ersatzfernbedienung

	Digital		Display / Media
	Yellow/Theater Modes/Info		Yellow / YouTube / Repeat
	Power		Power
	TV		Shift + 1
	DVD		Shift + 2
	Green/Stereo/[...]		Green / APP / Repeat
	Blue/Delay/Title		Blue / Prime Video / Random
	Red/Center/Audio		Red / Netflix / Search
	Up		Up
	Violet/Level/Came		Fav / Marker / PC
	Tape		Shift + 5
	SAT/CAB		Shift + 0
	Tuner		Shift + 6
	Video/VCR		Shift + 4
	Left/-		Left
	OK		OK
	Right/+		Right

Originalfernbedienung Ersatzfernbedienung

	Down		Down
	Menu/RDS		Menu / Home
	Vol+		Vol+
	PR+ />>I		>>I / Preset+
	PR+ />>I		CH+ / Page+
	Vol-		Vol-
	PR- /I<<		I<< / Preset-
	PR- /I<<		CH- / Page-
	Mute		Mute / Dimmer
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8




Originalfernbedienung Ersatzfernbedienung

	9		9
	Memo/Clear		Smart / List
	0		0
	<<		<< / Tune-
	Play		Play / Slow
	>>		>> / Tune+
	Rec		Rec / Rec Mode
	Stop		Stop / Hold
	Pause		Pause / Step / Freeze

Originalfernbedienung Ersatzfernbedienung





Originalfernbedienung Ersatzfernbedienung

	Digital		Display / Media
	Yellow/ThaterMo des/Info		Yellow / YouTube / Repeat
	Power		Power
	TV		Shift + 1
	DVD		Shift + 2
	Green/Stereo/[...]		Green / APP / Repeat
	Blue/Delay/Title		Blue / Prime Video / Random
	Red/Center/Audio		Red / Netflix / Search
	Up		Up
	Violet/Level/Came		Fav / Marker / PC
	Tape		Shift + 5
	SAT/CAB		Shift + 0
	Tuner		Shift + 6
	Video/VCR		Shift + 4
	Left/-		Left
	OK		OK
	Right/+		Right

Originalfernbedienung Ersatzfernbedienung

	PTY		Text / Goto
	Down		Down
	Menu/RDS		Menu / Home
	Vol+		Vol+
	PR+ />>I		CH+ / Page+
	Vol-		Vol-
	PR- /I<<		CH- / Page-
	Mute		Mute / Dimmer
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9





Originalfernbedienung Ersatzfernbedienung



































	Memo/Clear		Smart / List
	0		0
	<<		<< / Tune-
	Play		Play / Slow
	>>		>> / Tune+
	Rec		Rec / Rec Mode
	Stop		Stop / Hold
	Pause		Pause / Step / Freeze

Originalfernbedienung Ersatzfernbedienung









Originalfernbedienung Ersatzfernbedienung

























	Digital		Display / Media
	Yellow/Theater Modes/Info		Yellow / YouTube / Repeat
	Power		Power
	Tv		Shift + 1
	DVD		Shift + 2
	Green/Stereo/[...]		Green / APP / Repeat
	Blue/Delay/Title		Blue / Prime Video / Random
	Red/Center/Audio		Audio / Lang I/II
	Red/Center/Audio		Red / Netflix / Search
	Up		Up
	Violet/Camera/Le		Fav / Marker / PC
	Tape		Shift + 5
	SAT/CAB		Shift + 0
	Tuner		Shift + 6
	Video/VCR		Shift + 4
	Left/-		Left
	OK		OK

Originalfernbedienung Ersatzfernbedienung

	Right/+		Right
	PTY		Text / Goto
	Down		Down
	Menu/RDS		Menu / Home
	Menu/RDS		AV / Input / RDS
	Vol+		Vol+
	PR+ />>I		CH+ / Page+
	PR+ />>I		>>I / Preset+
	Vol-		Vol-
	PR-/I<<		CH- / Page-
	PR-/I<<		I<< / Preset-
	Mute		Mute / Dimmer
	1		1
	2		2
	3		3
	4		4
	5		5





Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung		Ersatzfernbedienung	
	6		6				
	7		7				
	8		8				
	9		9				
	Memo/Clear		Smart / List				
	0		0				
	<<		<< / Tune-				
	Play		Play / Slow				
	>>		>> / Tune+				
	Rec		Rec / Rec Mode				
	Stop		Stop / Hold				
	Pause		Pause / Step / Freeze				

