



































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Source		AV / Input / RDS
	Picture		Picture / Format
	Sound		Sound / Title
	Still		Pause / Step / Freeze
	Mute		Mute / Dimmer
	1		1
	2		2
	3		3
	Red		Red / Netflix / Search
	4		4
	5		5
	6		6
	Green		Green / APP / Repeat
	7		7
	8		8
	9		9

Originalfernbedienung Ersatzfernbedienung

	Yellow		Yellow / YouTube / Repeat
	Menu		Menu / Home
	0		0
	Exit		Exit / Cancel / Clear
	Blue		Blue / Prime Video / Random
	Up		Up
	Left		Left
	OK		OK
	Right		Right
	Down		Down
	CH -		CH- / Page-
	CH +		CH+ / Page+
	Vol -		Vol-
	Vol +		Vol+
	Guide / Size		Guide / EPG / -/--
	Index / Subtitle		Subtitle / EQ
	Sleep		Sleep / Timer



