



































Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
On/Off		Power	
Mute		Mute	
Update		Smart	
Reveal		Media	
Subt.List		Subt	
Sleep Timer		Sleep	
Txt Stop		Stop	
Info		Info	
Menu video		D. Menu	
Return TV		TV/R	
Txt Expand		Eject	
Text		Text	
Menu		Menu	
Menu Up		Up	
Display		Shift + Info	
TV/AV		AV	
Menu Left		Left	
OK Enter		Ok	
Menu Right		Right	
Menu Off		Exit	
Menu Down		Down	
Back		Back	
Volume+		Vol +	
Chan.Up		Ch +	
Menu audio		Dual	
Volume-		Vol -	
Chan.Down		Ch -	
1		1	
2		2	
3		3	
4		4	
5		5	
6		6	
7		7	



