





































Originalfernbedienung Ersatzfernbedienung

On/Off		Power
Audio Off		Mute
Slow Down		Ch -
Slow Up		Ch +
Pause		Pause
Auto/Track		Smart
Stop		Stop
Subt.		Subt
Title		List
Rep/A-B		TV/R
Pepeat/1/All		Text
Zoom		Shift + Eject
DVD/TV		AV
Menu		Menu
Menu Up		Up
Display		Info
Return		Back

Originalfernbedienung Ersatzfernbedienung



















Menu Left		Left
OK Enter		Ok
Progr.		Sleep
Next		>>
Menu Right		Right
Prev.		<<
Menu Down		Down
Volume+		Vol +
Volume-		Vol -
Top Menu		D. Menu
1		1
2		2
3		3
4		4
5		5
Store		Red
6		6




















Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
Digest		Angle	 Format
7		Np	 +  Shift + Subt
Open/Close		Info	 +  Shift + Info
8			
9			
Clear/00:00			
+10			
Record			
Auto Scan			
Rewind			
Play			
F.Forward			
Setup			
Audio			
3D			
0			
C/CH			








Originalfernbedienung Ersatzfernbedienung

On/Off		Power
Audio Off		Mute
Stop		Stop
Pause		Pause
Slow Up		Ch +
Slow Down		Ch -
Subt.		Subt
Auto/Track		Sleep
Rep/A-B		TV/R
Zoom	 + 	Shift + Eject
Title		List
Pepeat/1/All		Text
DVD/TV		AV
Menu		Menu
Menu Up		Up
Display		Info
Menu Left		Left

Originalfernbedienung Ersatzfernbedienung


















OK Enter		Ok
Menu Right		Right
Return		Exit
Menu Down		Down
Progr.		Back
Volume+		Vol +
Top Menu		D. Menu
Next		>>I
Volume-		Vol -
1		1
2		2
3		3
Prev.		I<<
4		4
5		5
6		6
7		7




















Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
8			8
Video			Smart
9			9
+10			Guide
0			0
C/CH			Pre Ch
Rewind			<<
Random			Media
Angle			Format
R/L	 + 		Shift + Info
Play			Play
Record			Rec
F.Forward			>>
3D			3D
Open/Close			Eject
Audio			Dual



Originalfernbedienung Ersatzfernbedienung

On/Off		Power
Audio Off		Mute
Slow Down		Ch -
Slow Up		Ch +
Auto/Track		Smart
Stop		Stop
Subt.		Subt
Pause		Pause
Zoom		Shift + Eject
Title		List
Rep/A-B		TV/R
Pepeat/1/All		Text
DVD/TV		AV
Menu		Menu
Menu Up		Up
Display		Info
Menu Left		Left

Originalfernbedienung Ersatzfernbedienung

OK Enter		Ok
Menu Right		Right
Return		Back
Menu Down		Down
Next		>>
Progr.		Sleep
Volume+		Vol +
Top Menu		D. Menu
Volume-		Vol -
Prev.		<<
1		1
2		2
3		3
4		4
5		5
6		6
7		7



Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
8		8	
Open/Close		Eject	
Mode		Media	
9		9	
Setup		Options	
+10		Guide	
3D		3D	
0		0	
C/CH		Pre Ch	
Play/Back	 + 	Shift + Left	
Resume	 + 	Shift + Play	
Play		Play	
Karaoke/Step	 + 	Shift + Pause	
Np	 + 	Shift + Subt	
Record		Rec	
F.Forward		>>	
Rewind		<<	
Store	 + 	Shift + Down	
Angle		Format	
Lang		Dual	

