






































































Originalfernbedienung Ersatzfernbedienung



































	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	PIP/Audio		3D
	[<>]		Format
	?		Smart
	Mute		Mute
	Z/Disc Menu		Menu
	i/OSD		Info

Originalfernbedienung Ersatzfernbedienung



































	TXT		Text
	TV-G		Guide
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	P+		Ch +
	P-		Ch -
	Vol+		Vol +
	Vol-		Vol -
	Red/Image/I>		Red
	Green/Timer		Green
	Yellow/@		Yellow
	Blue/Sound		Blue
	Play		Play
	Pause		Pause




Originalfernbedienung Ersatzfernbedienung

	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	PIP/Audio		3D
	[<>]		Format
	?		Smart
	i/OSD		Info
	TXT		Text
	TV-G		Guide


































Originalfernbedienung Ersatzfernbedienung

	Z/Disc Menu		Menu
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	P+		Ch +
	P-		Ch -
	Vol+		Vol +
	Vol-		Vol -
	Red/Image/I>		Red
	Green/Timer		Green
	Yellow/@		Yellow
	Blue/Sound		Blue
	Play		Play
	Pause		Pause
	Stop		Stop













Originalfernbedienung Ersatzfernbedienung

	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	PIP/Audio		3D
	[<>]		Format
	?		Smart
	Mute		Mute
	i/OSD		Info
	TXT		Text



































Originalfernbedienung Ersatzfernbedienung

	Z/Disc Menu		Menu
	TV-G		Guide
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	P+		Ch +
	P-		Ch -
	Vol+		Vol +
	Vol-		Vol -
	Red/Image/I>		Red
	Green/Timer		Green
	Yellow/@		Yellow
	Blue/Sound		Blue
	Play		Play
	Pause		Pause














Originalfernbedienung Ersatzfernbedienung

	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	PIP/Audio		3D
	[<>]		Format
	?		Smart
	i/OSD		Info
	TXT		Text
	TV-G		Guide

Originalfernbedienung Ersatzfernbedienung

	Z/Disc Menu		Menu
	P+		Ch +
	P-		Ch -
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Vol+		Vol +
	Vol-		Vol -
	Red/Image/I>		Red
	Green/Timer		Green
	Yellow/@		Yellow
	Blue/Sound		Blue
	Play		Play
	Pause		Pause
	Stop		Stop



