




































Originalfernbedienung Ersatzfernbedienung

 VHS/DVD Power	 Power
 Direct TV Rec	 Subt
 VHS/DVD	 Smart
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Cancel / Reset	 Exit
 Input Select	 Guide
 CH+ / Tracking/V-Lock+	 Ch +
 CH- / Tracking/V-Lock-	 Ch -













Originalfernbedienung Ersatzfernbedienung

 Create Chapter	 TV/R
 I<< Skip	 I<<
 Skip >>I	 >>I
 REW / << Slow/Search	 <<
 FF / Slow/Search	 >>
 Stop	 Stop
 Pause	 Pause
 Play	 Play
 Direct Navigator / Top Menu	 D. Menu
 Functions	 List
 Up	 Up
 Left	 Left
 Enter	 Ok
 Right	 Right
 Down	 Down
 Sub Menu	 Menu
 Return	 Back






Originalfernbedienung Ersatzfernbedienung



































	Power		Power
	AV		AV
	Volume+		Vol +
	Volume-		Vol -
	CH+		Ch +
	CH-		Ch -

Originalfernbedienung Ersatzfernbedienung





Originalfernbedienung Ersatzfernbedienung

 VHS/DVD Power	 Power
 Direct TV Rec	 Subt
 VHS/DVD	 Smart
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Cancel / Reset	 Exit
 Input Select	 AV
 CH+ / Tracking/V-Lock+	 Ch +
 CH- / Tracking/V-Lock-	 Ch -

Originalfernbedienung Ersatzfernbedienung

 ShowView	 Media
 I<< Index	 I<<
 Index >>I	 I>>
 REW	 REW
 FF	 FF
 Stop	 Stop
 Pause	 Pause
 Play	 Play
 Up	 Up
 Left	 Left
 Enter	 Ok
 Right	 Right
 Down	 Down
 Return	 Back
 Prog/Check	 Sleep
 Display	 Info
 Jet Rew	 Shift + I<<



