








































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Source		AV
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	TTX/MIX		Text
	PRE-CH		Pre Ch
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute

















Originalfernbedienung Ersatzfernbedienung

	PR+		Ch +
	PR-		Ch -
	CH List		List
	Content		Smart
	Menu		Menu
	Guide		Guide
	Info		Info
	Tools		Options
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter		Ok
	Return		Back
	Exit		Exit
	Red/A		Red
	Green/B		Green





Originalfernbedienung Ersatzfernbedienung

	Yellow/C		Yellow
	Blue/D		Blue
	Internet TV		TV/R
	Media.P		Media
	Dual I-II		Dual
	AD		Shift + Subt
	P.Size		Format
	Subt.		Subt
	<<		<<
	Pause		Pause
	>>		>>
	Rec		Rec
	Play		Play
	Stop		Stop

Originalfernbedienung Ersatzfernbedienung

