



























































	Original	Replacement		Original	Replacement
	Standby		Power		Tv/Radio
	Source		AV		TV/R
	1		1		Vol +
	2		2		Vol -
	3		3		Mute
	4		4		Mute
	5		5		Ch +
	6		6		Ch -
	7		7		Menu
	8		8		Exit
	9		9		Up
	0		0		Down
	[*]/Display		Info		Right
	Recall		Back		Left
	Freeze		Options		Enter
	P.Mode		Format		TXT
	S.Mode		Dual		Play
					Pause/Time Shift
					Stop/EPG
					Play
					Pause
					Stop



