




































Original	Replacement
	 Power
	 Mute / Dimmer
	 Red / Netflix / Search
	 Green / APP / Repeat
	 Yellow / YouTube / Repeat
	 Blue / Prime Video / Random
	 Picture / Format
	 D.Menu / Top
	 Text / Goto
	 Sound / Title
	 I<< / Preset-
	 >>I / Preset+
	 << / Tune-
	 >> / Tune+
	 Play / Slow
	 Pause / Step / Freeze
	 Stop / Hold

Original	Replacement
	 Rec / Rec Mode
	 Smart / List
	 Menu / Home
	 Up
	 Exit / Cancel / Clear
	 Left
	 OK
	 Right
	 Guide / EPG / -/--
	 Down
	 Info / Angle
	 CH+ / Page+
	 CH- / Page-
	 TV/Radio /
	 Vol+
	 Vol-
	 Audio / Lang I/II





Original		Replacement		Original		Replacement	
	1		1				
	2		2				
	3		3				
	4		4				
	5		5				
	6		6				
	7		7				
	8		8				
	9		9				
	0		0				
	FAV		Fav / Marker / PC				
	Recall		Back / Return				

