






































































Original	Replacement	Original	Replacement
 Power	 Power	 Vol-	 Vol-
 Mute	 Mute / Dimmer	 Home	 Menu / Home
 1	 1	 P-	 CH- / Page-
 2	 2	 *	 D.Menu / Top
 3	 3	 Up	 Up
 4	 4	 i	 Info / Angle
 5	 5	 Left	 Left
 6	 6	 OK	 OK
 7	 7	 Right	 Right
 8	 8	 Back	 Back / Return
 9	 9	 Down	 Down
 EPG	 Guide / EPG / -/--	 Exit	 Exit / Cancel / Clear
 0	 0	 Netflix	 Shift + Red / Netflix /
 TXT	 Text / Goto	 YouTube	 Shift + Yellow / YouTube /
 Vol+	 Vol+	 *1	 Smart / List
 Input	 AV / Input / RDS	 *2	 Display / Media
 P+	 CH+ / Page+	 Red	 Red / Netflix / Search



