


















































































Original	Replacement	Original	Replacement
 Power	 Power	 Left	 Left
 Mute	 Mute / Dimmer	 Check	 OK
 Play/Pause	 Play / Slow	 Right	 Right
 Stop	 Stop / Hold	 Clear	 Exit / Cancel / Clear
 I<<	 I<< / Preset-	 Down	 Down
 >>I	 >>I / Preset+	 Volume Control +	 Vol+
 EQ.Effect	 Sound / Title	 M.Call	 Smart / List
 S.W.Effect	 Audio / Lang I/II	 P.Call Up	 CH+ / Page+
 P.Open/Close	 Eject / Surround	 Volume Control -	 Vol-
 P.Mode	 Picture / Format	 Display	 Display / Media
 Sleep	 Sleep / Timer	 P.Call Down	 CH- / Page-
 Tuner Band	 TV/Radio /	 1	 1
 Presence	 D.Menu / Top	 2	 2
 AI/Loudness	 Setup / OPT /	 3	 3
 AI/Auto/Focus/GE	 Text / Goto	 4	 4
 LD/AUX	 AV / Input / RDS	 5	 5
 Up	 Up	 6	 6





Original	Replacement
	 7
	 8
	 9
+10	 Guide / EPG / -/--
	 0
Edit	 Fav / Marker / PC
Repeat	 Green / APP / Repeat
S.W.Power	 +  Shift + Power
Off	 +  Shift + Mute / Dimmer
S.W.Vol+	 +  Shift + Vol+
P	 +  Shift + Smart / List
S.W.Vol-	 +  Shift + Vol-
	 +  Shift + 1
	 +  Shift + 2
CD	 +  Shift + 3
	 +  Shift + 4
Tape	 +  Shift + 5

Original	Replacement
Tuner	 +  Shift + 6
Changer CD 3	 +  Shift + 7
Changer CD 5	 +  Shift + 8
Changer CD 6	 +  Shift + 9



