







































































Original	Replacement	Original	Replacement
	Power		Power
	[ + ]		Display / Media
	Mute		Mute / Dimmer
	Tv/AV		AV / Input / RDS
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Vol+		Vol+
	Vol-		Vol-
	Timer		Sleep / Timer
	1		1
	N		D.Menu / Top
	F		Menu / Home
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	-/--		Guide / EPG / -/--
	0/VCR		0
	0/VCR		Shift + 4
	Red		Red / Netflix / Search
	C		Exit / Cancel / Clear
	Green		Green / APP / Repeat
	Blue		Blue / Prime Video / Random
	Hold		Shift + Stop /
	Yellow		Yellow / YouTube / Repeat
	Index		Info / Angle
	Pause/Step		Pause / Step / Freeze
	Reveal		Smart / List





Original	Replacement
 Time Text	 TV/Radio /
 Play	 Play / Slow
 Tv/Text	 Text / Goto
 Stop	 Stop / Hold
 >>	 >> / Tune+
 <<	 << / Tune-
 Rec	 Rec / Rec Mode
 F/T/B	 Zoom / Size
 Power VCR	 Shift + Power
 Programme Up	 CH+ / Page+
 Programme Down	 CH- / Page-

Original	Replacement

