



































































Original	Replacement
 Power	 Power
 Open/Close	 Eject / Surround
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Cancel	 Shift + Exit / Cancel / Clear
 Audio	 Audio / Lang I/II
 Receiver Vol+	 Vol+
 Receiver Vol-	 Vol-
 Receiver Mute	 Mute / Dimmer

Original	Replacement
 Vieta Cast	 Smart / List
 I<< Skip	 I<< / Preset-
 Skip >>I	 >>I / Preset+
 << Slow/Search	 << / Tune-
 Slow/Search >>	 >> / Tune+
 Stop	 Stop / Hold
 Pause	 Pause / Step / Freeze
 Play	 Play / Slow
 Status	 Text / Goto
 Exit	 Exit / Cancel / Clear
 Option	 Shift + Setup / OPT / Tools
 Return	 Back / Return
 Top Menu/Direct Navigator	 D.Menu / Top
 Pop-Up Menu	 Shift + Menu /
 Function Menu	 Menu / Home
 Up	 Up
 Down	 Down





Original	Replacement	Original	Replacement
	Right		Right
	Left		Left
	OK		OK
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	Setup		Setup / OPT /
	PIP		Picture / Format
	Display		Display / Media
	Select Drive		AV / Input / RDS
	Power Tv		Shift + Power
	AV Tv		Shift + AV / Input / RDS
	TV Vol+		Shift + Vol+
	TV Vol-		Shift + Vol-
	TV CH+		CH+ / Page+
	TV CH-		CH- / Page-

