























































Original	Replacement
 Power	 Power
 Mute	 Mute / Dimmer
 Open/Close	 Eject / Surround
 Setup	 Setup / OPT /
 N/P	 Picture / Format
 DVD/DVB/Card	 AV / Input / RDS
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0/10	 0
 10+	 Guide / EPG / -/--

Original	Replacement
 Display	 Display / Media
 PBC	 Smart / List
 Title	 Sound / Title
 Menu	 Menu / Home
 Up	 Up
 Left	 Left
 Enter	 OK
 Right	 Right
 Down	 Down
 Search	 Shift + Red / Netflix /
 Mark	 Fav / Marker / PC
 Program	 Shift + TV/Radio / Program
 Zoom	 Zoom / Size
 Stop	 Stop / Hold
 Pause	 Pause / Step / Freeze
 Play	 Play / Slow
 Vol+	 Vol+





Original	Replacement	Original	Replacement
I<<	I<< / Preset-		
>>I	>>I / Preset+		
Vol-	Vol-		
<<	<< / Tune-		
>>	>> / Tune+		
Audio	Audio / Lang I/II		
Subtitle	Subtitle / EQ		
Angle/Scan	Info / Angle		
Tv/Radio/A-B	TV/Radio /		
TTX/3D	Text / Goto		
Red/FAV/Step	Red / Netflix / Search		
Green/Del/Slow	Green / APP / Repeat		
Yellow/Pro/V-Mod	Yellow / YouTube / Repeat		
Blue/EPG/Repea	Blue / Prime Video / Random		
A1	Shift + 1		
A2	Shift + 2		
A3	Shift + 3		

