




































Original	Replacement	Original	Replacement
 Standby	 Power	 Right	 Right
 Info	 Info / Angle	 Vol+	 Vol+
 Subtitle	 Subtitle / EQ	 Record	 Rec / Rec Mode
 Mute	 Mute / Dimmer	 Down	 Down
 I<<	 I<< / Preset-	 CH-	 CH- / Page-
 Play	 Play / Slow	 Stop	 Stop / Hold
 <<	 << / Tune-	 1	 1
 >>I	 >>I / Preset+	 2	 2
 Pause	 Pause / Step / Freeze	 3	 3
 >>	 >> / Tune+	 EPG	 Guide / EPG / -/-
 Menu	 Menu / Home	 4	 4
 Up	 Up	 5	 5
 CH+	 CH+ / Page+	 6	 6
 Exit	 Exit / Cancel / Clear	 Back	 Back / Return
 Left	 Left	 7	 7
 Vol-	 Vol-	 8	 8
 OK	 OK	 9	 9

Original	Replacement	Original	Replacement
 Right	 Right	 Right	 Right
 Vol+	 Vol+	 Vol+	 Vol+
 Record	 Rec / Rec Mode	 Record	 Rec / Rec Mode
 Down	 Down	 Down	 Down
 CH-	 CH- / Page-	 CH-	 CH- / Page-
 Stop	 Stop / Hold	 Stop	 Stop / Hold
 1	 1	 1	 1
 2	 2	 2	 2
 3	 3	 3	 3
 EPG	 Guide / EPG / -/-	 EPG	 Guide / EPG / -/-
 4	 4	 4	 4
 5	 5	 5	 5
 6	 6	 6	 6
 Back	 Back / Return	 Back	 Back / Return
 7	 7	 7	 7
 8	 8	 8	 8
 9	 9	 9	 9





Original	Replacement
	0
	Display / Media
	+ Shift + 8
	TV/Radio /
	Audio / Lang I/II
	Text / Goto
	Sleep / Timer
	Fav / Marker / PC
	D.Menu / Top
	Red / Netflix / Search
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random

Original	Replacement

