






































Original	Replacement
 Power	 Power
 TV / Video	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 /--	 Guide
 Quick	 Pre Ch
 Mute	 Mute
 Sleep	 Sleep
 Skip	 Exit

Original	Replacement
 Display	 Info
 Up / Prog +	 Ch +
 Up / Prog +	 Up
 Down / Prog -	 Ch -
 Down / Prog -	 Down
 Right / Vol +	 Vol +
 Right / Vol +	 Right
 Left / Vol -	 Vol -
 Left / Vol -	 Left
 Menu	 Menu
 Menu	 Ok
 P-STD	 Shift + Format
 S-STD	 Dual
 PC Auto ADJ	 Smart
 PC / TV/PC	 Media
 M / S	 TV/R
 Surround	 Shift + Dual





Original	Replacement
Wide	Format
OSD Position	3D
OSD Language	Shift + 3D
Setup	Options
Red	Red
Green	Green
List / FLOF	List
Yellow	Yellow
Blue	Blue
Mix	Shift + Text
Index	Shift + Info
TV / Text	Text
Cancel	Back
Subpage	Subt
Reveal	Play
Page -	I<<
Page +	>>I

Original	Replacement
Size	Eject
Hold	Stop
Store	Shift + Smart

