











	Original	Replacement		Original	Replacement
	Power		Power		0
	Up		Up		Guide
	Down		Down		Back
	Right		Right		Ch +
	Left		Left		Ch -
	OK		Ok		Pre Ch
	M		Menu		Vol +
	[i]		Info		Vol -
	1		1		Mute
	2		2		Dual
	3		3		TV/R
	4		4		AV
	5		5		Red
	6		6		Green
	7		7		Yellow
	8		8		Blue
	9		9		Text



