






































	Original	Rechange	Original	Rechange
	Power			Ok
	Mute			Up
	1			Down
	2			Right
	3			Left
	4			Vol +
	5			Vol -
	6			Ch +
	7			Ch -
	8			Stop
	9			Play
	0			Rec
	Thumb			>>
	Time Shift			<<
	Menu			EPG/BG-Music
	Exit			Shift + Options
	Info			Text
				Eject



