





























































	Original	Rechange		Original	Rechange
	1		1		A-B
	2		2		Angle
	3		3		Repeat
	4		4		OSD
	5		5		Return
	6		6		Enter
	7		7		Vol-
	8		8		Vol+
	9		9		Mute
	0		0		Stop
	Zoom		Eject		Play
	Menu		Menu		Pause
	Audio		Dual		<<
	Subtitle		Subt		>>
	Title		Info		Left
	Mode		Pre Ch		Right
	Setup		Options		I<<
					I<<





	Original	Recharge	Original	Recharge
		>>		>>
		<<		Up
		>>		Down

