
















Original		Rechange		Original		Rechange	
	Power		Power		5		5
	Mute		Mute		6		6
	DTV / Radio		TV/R		7		7
	AVC		Smart		8		8
	Info		Info		9		9
	TV Audio		Dual		0		0
	DTV / TV		Shift + TV/R		Recall		Back
	Sleep		Sleep		Vol+		Vol +
	Wide		Format		Vol-		Vol -
	Subtitle		Subt		Guide		Guide
	Freeze		Pause		List		List
	Picture		Shift + Format		Prog+		Ch +
	Sound		Shift + Dual		Prog-		Ch -
	1		1		Exit		Exit
	2		2		Favorite		Pre Ch
	3		3		Up		Up
	4		4		Left		Left





Original		Recharge		Original	Recharge
	OK		Ok		
	Right		Right		
	Down		Down		
	Input		AV		
	Menu		Menu		
	TXT Hold		Stop		
	TXT Update		Shift + Exit		
	TXT Subcode		Shift + Subt		
	Text / Mix		Text		
	TXT Index		Options		
	TXT List		Shift + List		
	TXT Size		Eject		
	TXT Reveal		Media		
	Red		Red		
	Green		Green		
	Yellow		Yellow		
	Blue		Blue		

