



















	Original	Rechange	Original	Rechange
	Power			
	Muting			
	Function			
	Display			
	Preset			
	Surround			
	Master Vol+			
	Master Vol-			
	>>I			
	I<<			
	Enter			
	Pause			
	Stop			
	<<			
	>>			
	Play	