






















































































Original	Rechange	Original	Rechange
 Power	 Power	 Blue/Picture	 Blue
 Mute	 Mute	 O/I/I	 Dual
 1	 1	 Menu	 Menu
 2	 2	 Up	 Up
 3	 3	 Down	 Down
 4	 4	 Right	 Right
 5	 5	 Left	 Left
 6	 6	 OK	 Ok
 7	 7	 [≡]	 Text
 8	 8	 Back	 Back
 9	 9	 P+	 Ch +
 0	 0	 P-	 Ch -
 i	 Info	 Vol+	 Vol +
 AV	 AV	 Vol-	 Vol -
 Red/Zoom	 Red	 ^/[+]	 Format
 Green/(↔)	 Green	 Play/[?]	 Play
 Yellow/Timer	 Yellow	 >>/[♦]	 >>

















































































Original	Recharge	Original	Recharge
 ^/Timer	 Options		
 Stop/[X]	 Stop		
 Pause/[≡i]	 Pause		
 [■]	 Subt		
 [←■]	 TV/R		
 [↕■]	 3D		
 ♪	 +  Shift + Dual		























Original	Rechange	Original	Rechange
 Power	 Power	 P-	 Ch -
 Mute	 Mute	 Vol+	 Vol +
 1	 1	 Vol-	 Vol -
 2	 2	 Red/Zoom	 Red
 3	 3	 Green/(↔)	 Green
 4	 4	 Yellow/Timer	 Yellow
 5	 5	 Blue/Picture	 Blue
 6	 6		
 7	 7		
 8	 8		
 9	 9		
 0	 0		
 AV	 AV		 Format
 i	 Info		 Options
 O)/I/II	 Dual	 Rec/Top Menu	 Rec
 PC	 Text		 Play
 [≡]	 Ch +		 Stop
 P+			 Pause
			 Subt
			 TV/R









































































Original		Rechange		Original		Rechange	
	[↕ ■]		3D				
	♪		Shift + Dual				
	Menu		Menu				
	Back		Back				
	OK		Ok				
	Up		Up				
	Down		Down				
	Right		Right				
	Left		Left				





Original	Rechange	Original	Rechange
 Power	 Power	 Green/(↔)	 Green
 Mute	 Mute	 Yellow/Timer	 Yellow
 1	 1	 Blue/Picture	 Blue
 2	 2	 OK	 Ok
 3	 3	 Up	 Up
 4	 4	 Down	 Down
 5	 5	 Right	 Right
 6	 6	 Left	 Left
 7	 7	 P+	 Ch +
 8	 8	 P-	 Ch -
 9	 9	 Vol+	 Vol +
 0	 0	 Vol-	 Vol -
 i	 Info	 <<	 <<
 AV	 AV	 Play/[?]	 Play
 O/I/II	 Dual	 >>/[♦]	 >>
 Menu	 Menu	 Stop/[X]	 Stop
 Red/Zoom	 Red	 Pause/[≡i]	 Pause





Original	Rechange	Original	Rechange
^/[+]	Format		
√/Timer	Options		
[■]	Subt		
[←■]	TV/R		
[↑■]	3D		
♪	Shift + Dual		
Back	Back		
[≡]	Text		

