















































































Original		Rechange		Original		Rechange	
	Main Power On		Power		4		4
	Main Power Off		Shift + Power		5		5
	Source Power		AV		6		6
	Mute		Mute		7		7
	Volume+		Vol +		8		8
	Volume-		Vol -		9		9
	Phono		Shift + 1		0		0
	CD		Shift + 2		+		Pre Ch
	Tuner		Shift + 3		-		Guide
	Recorder 1 /CD-R		Shift + 4		A F/P		Smart
	AUX		Shift + 5		B -/--		Media
	DVD		Shift + 6		Mode		Format
	Recorder		Shift + 7		Memo		Rec
	Recorder 2/MD		Shift + 8		SCroll		Info
	1		1		Cancel		Back
	2		2		Text/1 Mode		Text
	3		3		Time/Mode 2		3D


































































Original	Rechange	Original	Rechange
	>>		>>
	<<		<<
	<<		<<
	>>		>>










































































Original		Recharge		Original		Recharge	
	Main Power On		Power		Text/1 Mode		Text
	Main Power Off	 + 	Shift + Power		Time/Mode 2		3D
	Source Power		AV		Mute		Mute
	1		1		Volume+		Vol +
	2		2		Volume-		Vol -
	3		3		Play		Play
	4		4		>>		>>
	5		5		<<		<<
	6		6		Stop		Stop
	7		7		<<		<<
	8		8		>>		>>
	9		9		Pause		Pause
	0		0		Open/Close		Eject
	+		Pre Ch				
	-		Guide				
	A F/P		Smart				
	B -/--		Media				










































































Original		Rechange		Original		Rechange	
	Main Power On		Power		-		Guide
	Main Power Off	 + 	Shift + Power		A F/P		Smart
	Source Power		AV		B -/--		Media
	Mute		Mute		Mode		Format
	Volume+		Vol +		Memo		Rec
	Volume-		Vol -		Scroll		Info
	1		1		Cancel		Back
	2		2		Text/1 Mode		Text
	3		3		Time/Mode 2		3D
	4		4		Play		Play
	5		5		>>		>>
	6		6		<<		<<
	7		7		Stop		Stop
	8		8		>>		>>
	9		9		<<		<<
	0		0		Pause		Pause
	+		Pre Ch		Open/Close		Eject





Original	Rechange	Original	Rechange
 Main Power On	 Power	 Mode	 Format
 Main Power Off	 +  Shift + Power	 Memo	 Rec
 Source Power	 AV	 Cancel	 Back
 1	 1	 Text/1 Mode	 Text
 2	 2	 Time/Mode 2	 3D
 3	 3	 Mute	 Mute
 4	 4	 Volume+	 Vol +
 5	 5	 Volume-	 Vol -
 6	 6	 Play	 Play
 7	 7	 >>	 >>
 8	 8	 <<	 <<
 9	 9	 Stop	 Stop
 0	 0	 >>	 >>
 +	 FAV PRE-CH Pre Ch	 <<	 <<
 -	 GUIDE Guide	 Pause	 Pause
 A F/P	 HOME SMART Smart	 <>	 Blue
 B -/-	 APP MEDIA Media	 Open/Close	 Eject

