

















































































Original		Recharge		Original		Recharge	
	Power		Power		i		Info
	AV		AV		P+		Ch +
	1		1		P-		Ch -
	2		2		Menu		Menu
	3		3		Exit		Exit
	4		4		Option		Options
	5		5		Back/Return		Back
	6		6		Up		Up
	7		7		Down		Down
	8		8		Right		Right
	9		9		Left		Left
	0		0		OK		Ok
	Still		Format		TV		TV/R
	Recall		Pre Ch		Media		Media
	Vol+		Vol +		Guide		Guide
	Vol-		Vol -		[+]		3D
	Mute		Mute		Timer		Shift + AV





	Original	Recharge		Original	Recharge
	Text				
	Red				
	Green				
	Yellow				
	Blue				
	Audio				
	STTL				
	Sound				
	<<				
	Pause				
	>>				
	Rec				
	Play				
	Stop	