









































Originale	Sostituto
 Power Tv	 Power
 Tv/Video	 TV/R
 CH+	 Ch +
 CH-	 Ch -
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 10/Tv Return	 Guide
 +10/100+	 Pre Ch
 Vol+	 Vol +

Originale	Sostituto
 Vol-	 Vol -
 Muting	 Mute































Originale	Sostituto
 Power Audio	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 10 / Tv Return	 Guide
 +10 / 100+	 Pre Ch
 CH+	 Ch +
 CH-	 Ch -
 Up	 Up
 Enter	 Ok

Originale	Sostituto
 Down	 Down
 Right/Presets Up	 Right
 Left/Presets Down	 Left
 Muting	 Mute
 Menu/PL	 Menu
 Top Menu/PG	 Shift + Menu
 On Screen	 3D
 Back / Rec	 Rec
 Stop / Memory	 Stop
 Play	 Play
 Pause/FM Mode	 Pause
 I<</Tuning-	 I<<
 >>I/Tuning+	 >>I
 <</Slow-	 <<
 >>/Slow+	 >>
 Audio	 Dual
 Angle	 Shift + 3D





Originale	Sostituto
 Zoom	 Eject
 Subtitle	 Subt
 Vol+	 Vol +
 Vol-	 Vol -
 Repeat	 Text
 Page	 List
 Surround	 Smart
 PTY Search	 AV
 TA/News/Info	 Info
 PTY Select-	 Shift + Left
 PTY Select+	 Shift + Right
 Level+	 Shift + Up
 Level-	 Shift + Down
 Sleep	 Sleep
 Return	 Back
 Display	 Shift + Info
 Play Mode	 Format

Originale	Sostituto
 STB Control	 Shift + Smart
 Dimmer	 Shift + Media
 USB Memory	 Media
 Cancel	 Exit
 DVD	 Blue
 iPod	 Red
 FM/AM	 Green
 VCR/Video Control	 Yellow
 Tv/Video	 TV/R
 Set Up	 D. Menu
 SPK Level	 Shift + AV
 Setting	 Options
 Treble/Bass	 Shift + Sleep
 Title/Group	 Shift + List
 VFP/Scan Mode	 Shift + Options
 Tv Sound	 Shift + Dual





	Originale	Sostituto		Sostituto
	Power VCR/STB		Power	
1	1	1	1	
2	2	2	2	
3	3	3	3	
4	4	4	4	
5	5	5	5	
6	6	6	6	
7	7	7	7	
8	8	8	8	
9	9	9	9	
0	0	0	0	
	Tv/Video		TV/R	
	CH+		Ch +	
	CH-		Ch -	
	Vol+		Vol +	
	Vol-		Vol -	
	Muting		Mute	

	Originale	Sostituto

