





























Originale	Sostituto
Audio Off	 Mute / Dimmer
Game	 Blue / Prime Video / Random
Pbc	 AV / Input / RDS
Digest	 Text / Goto
C/CH	 Sleep / Timer
Auto/Track	 Picture / Format
DVD/TV	 Smart / List
3D	 +  Shift + 3
Menu Down	 Down
Slow Down	 CH- / Page-
Slow Up	 CH+ / Page+
OK Enter	 OK
Menu Up	 Up
Progr.	 TV/Radio /
Menu Right	 Right
2	 2
Menu Left	 Left

Originale	Sostituto
Rep/A-B	 Yellow / YouTube / Repeat
Rewind	 << / Tune-
Repeat/1/All	 Green / APP / Repeat
Prev.	 I<< / Preset-
F.Forward	 >> / Tune+
3	 3
4	 4
5	 5
6	 6
7	 7
8	 8
9	 9
+10	 Guide / EPG / -/-
0	 0
1	 1
Angle	 Info / Angle
Play	 Play / Slow



Originale	Sostituto	Originale	Sostituto
Record	 Rec / Rec Mode		
Audio	 Audio / Lang I/II		
Setup	 Setup / OPT /		
Mark	 Fav / Marker / PC		
Open/Close	 Eject / Surround		
Menu	 Menu / Home		
Stop	 Stop / Hold		
Pause	 Pause / Step / Freeze		
Subt.	 Subtitle / EQ		
Title	 Sound / Title		
Zoom	 Zoom / Size		
On/Off	 Power		
Display	 Display / Media		
Return	 Back / Return		
Next	 >>I / Preset+		
Top Menu	 D.Menu / Top		

