





































Originale	Sostituto	Originale	Sostituto
	Power		Power
	Home		Smart
	>>I		>>I
	I<<		I<<
	>>		>>
	<<		<<
	Play		Play
	Pause		Pause
	Rec		Rec
	Stop		Stop
	EPG		Guide
	SAT		Options
	TXT		Text
	Find		Media
	Menu		Menu
	i		Info
	FAV		Pre Ch
	Exit		Exit
	CH+		Ch +
	CH-		Ch -
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Shift		AV
	USB		3D





Originale		Sostituto	
	Tv/Radio		TV/R
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Audio		Dual
	Recall		Back

Originale		Sostituto	

