







































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Cancel		Exit / Cancel / Clear
	Auto Off		Shift + Power		Repeat		Green / APP / Repeat
	Sleep		Sleep / Timer		Random		Blue / Prime Video / Random
	Muting		Mute / Dimmer		Tape		Shift + 5
	1		1		CD		Shift + 3
	2		2		Tuner		Shift + 6
	3		3		AUX		Shift + 7
	Disc		Display / Media		EQ		Subtitle / EQ
	4		4		3D AI		Smart / List
	5		5		<<		<< / Tune-
	6		6		<<		<< / Preset-
	+10		Guide / EPG / -/--		>>		>> / Preset+
	7		7		>>		>> / Tune+
	8		8		V.Bass		Sound / Title
	9		9		</▼		Left
	0		0		</▼		Down
	Program		TV/Radio /		</▼		CH- / Page-



Program



Originale		Sostituto		Originale		Sostituto	
	Stop		Stop / Hold				
	Play/Pause/▲		Play / Slow				
	Play/Pause/▲		Right				
	Play/Pause/▲		Pause / Step / Freeze				
	Play/Pause/▲		Up				
	Play/Pause/▲		CH+ / Page+				
	Volume-		Vol-				
	Volume+		Vol+				

