





































Originale	Sostituto
 Power	 Power
 TV/R	 TV/R
 Mute	 Mute
 Display	 Shift + Info
 Mode	 Options
 Time	 AV
 F1	 Shift + 1
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0

Originale	Sostituto
 Sleep	 Sleep
 USB	 Media
 Red / Audio	 Red
 Red / Audio	 Dual
 Green / Pause	 Green
 Green / Pause	 Shift + Pause
 Yellow / Zoom	 Yellow
 Yellow / Zoom	 Eject
 Blue / Info	 Blue
 Blue / Info	 Info
 Menu	 Menu
 Exit	 Exit
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down



