Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
POWER	Power	Power	Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI - SAT 0	0
PRE CH	PRE-CH	RETURN BACK	Back / Return
HDMI	HDMI	SHIFT + HDMI - SAT 0	Shift + 0
VIDEO	Video	SHIFT + VIDEO 4	Shift + 4
TV	TV	PROGRAM TV/RADIO	TV/Radio / Program
PC	PC	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC
VOL	Vol +	+ VOL	Vol +
Mute	Mute	DIMMER MUTE	Mute / Dimmer
CH	CH+	+ CH PAGE	CH+ / Page+
VOL	Vol -	VOL -	Vol -
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
CH	CH-	CH PAGE -	CH- / Page-
DUAL I-II	Dual I-II	LANG I/II AUDIO	Audio / Lang I/II
SOUND	♪/Sound	TITLE SOUND	Sound / Title
PICTURE	Picture	FORMAT PICTURE	Picture / Format
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
MENU EXIT	Menu	HOME MENU	Menu / Home
MENU EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear

Originalfernbedienung	Ersatzfernbedienung
Down	Down
Info	Info / Angle
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
Teletext	Text / Goto
Mix	Shift + Text /
Size	Shift + Zoom /
Subpage	Setup / OPT /
Index	Display / Media
Subtitle	Subtitle / EQ
Hold	Stop / Hold
Reveal	Shift + Back / Return
FAV	Fav / Marker / PC
CH-List	Smart / List
AD	D.Menu / Top
Menu	

Originalfernbedienung	Ersatzfernbedienung
Freeze	Pause / Step / Freeze