| Originalfernbedienung | | Ersatzfernbedienung | |
|---|---|---|---|
| DVD/VHS | DVD/VHS Power | | Power |
| TV | TV Power | SHIFT + | Shift + Power |
| CH ∧ | TV CH + | SHIFT + CH PAGE + | Shift + CH+ / |
| VOLUME + | TV Volume + | VOL + | Vol + |
| DRIVE SELECT | Drive Select | FORMAT PICTURE | Picture / Format |
| AV | TV AV | SHIFT + RDS AV INPUT | Shift + AV / Input / RDS |
| CH ∨ | TV CH - | SHIFT + CH PAGE − | Shift + CH- / |
| VOLUME − | TV Volume - | VOL − | Vol - |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD - STB 3 | 3 |
| TRACKING/V-LOCK/PAGE ∧ CH | CH + / Tracking/V-Lock | CH PAGE + | CH+ / Page+ |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| CH ∨ | CH - / Tracking/V-Lock | CH PAGE − | CH- / Page- |
| 7 | 7 | AUX - HDD 7 | 7 |

| Originalfernbedienung | | Ersatzfernbedienung | |
|---|---|---|---|
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| VIDEO Plus+ | VIDEO Plus+ | PROGRAM TV/RADIO | TV/Radio / |
| * RESET | * / Reset | PC FAV MARKER | Fav / Marker / PC |
| 0 | 0 | HDMI - SAT 0 | 0 |
| INPUT SELECT | Input Select | RDS AV INPUT | AV / Input / RDS |
| DELETE | Delete | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| SKIP/I | I<< | PRESET- | I<< / Preset- |
| INDEX | >>I | PRESET+ | >>I / Preset+ |
| REW | << | TUNE- | << / Tune- |
| FF | >> | TUNE+ | >> / Tune+ |
| STOP | Stop | HOLD | Stop / Hold |
| PAUSE | Pause | STEP - FREEZE | Pause / Step / Freeze |
| PLAY | Play | SLOW | Play / Slow |
| i | i | ANGLE INFO | Info / Angle |
| PROG/CHECK | Prog Check | OPT-TOOLS SETUP | Setup / OPT / |
| GUIDE | Guide | -/-- GUIDE EPG | Guide / EPG / -/-- |

| Originalfernbedienung | Ersatzfernbedienung |
|---|---|
| Direct Navigator | D.Menu / Top |
| Left / ⧏I | Left |
| Up | Up |
| Enter / OK | OK |
| Right / I⧐ | Right |
| Functions | Menu / Home |
| Sub Menu | Smart / List |
| Down | Down |
| Return | Back / Return |
| Red | Red / Netflix / Search |
| Green | Green / APP / Repeat |
| Yellow / Create Chapter | Yellow / YouTube / Repeat |
| Blue / Manual | Blue / Prime Video / Random |
| Rec | Rec / Rec Mode |
| Rec Mode | Shift + Rec / Rec Mode |
| Ext Link | Sound / Title |
| Direct TV Rec | Zoom / Size |

| Originalfernbedienung | Ersatzfernbedienung |
|---|---|
| Text | Text / Goto |
| STTL | Subtitle / EQ |
| Display | Display / Media |
| Time Slip / ⧏⧏ Rew | Shift + ⧏⧏ / |