Originalfernbedienung		Ersatzfernbedienung	
STANDBY	Standby		Power
OPEN/CLOSE	Open/Close	SURROUND	Eject / Surround
OSD	OSD	MEDIA DISPLAY	Display / Media
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
PROG	Prog	PROGRAM TV/RADIO	TV/Radio /
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
A-B	A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
GOTO	Goto	GOTO TEXT	Text / Goto
0/10	0/10	HDMI - SAT 0	0

Originalfernbedienung		Ersatzfernbedienung	
10+	10+	-/-- GUIDE EPG	Guide / EPG / -/--
ST/MO L/R	L/R/ST/Mo	TITLE SOUND	Sound / Title
P/N	P/N	Prime Video RANDOM	Blue / Prime Video / Random
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
MEM	Stop/Mem	HOLD ■	Stop / Hold
– STATIO	I<</Station-	PRESET- ⏮	I<< / Preset-
STATION +	>>I/Station+	PRESET+ ⏭	>>I / Preset+
FM/AM	Play/Pause/FM/AM	SLOW ▶	Play / Slow
SLOW	Slow	SHIFT + SLOW ▶	Shift + Play /
– SEARC	<</Search-	TUNE- ⏪	<< / Tune-
SEARCH +	>>/Search+	TUNE+ ⏩	>> / Tune+
STEP	Step	STEP - FREEZE ⏸	Pause / Step / Freeze
MENU	Menu	HOME MENU	Menu / Home
RETURN	Return	RETURN BACK	Back / Return
ANGLE	Angle	ANGLE INFO	Info / Angle
	Up		Up

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
Setup	Setup / OPT /	Source	AV / Input / RDS
Left	Left	Treb-	CH- / Page-
Enter	OK	Bass-	Shift + CH- /
Right	Right	Vol -	Vol -
Clock/Tv-Mode	Sleep / Timer		
Down	Down		
Title	Shift + Sound / Title		
Preview	Fav / Marker / PC		
Zoom	Zoom / Size		
DVD/USB/Card	D.Menu / Top		
PBC	Smart / List		
VFD	Picture / Format		
EQ	Shift + Subtitle / EQ		
Mute	Mute / Dimmer		
Treb+	CH+ / Page+		
Bass+	Shift + CH+ /		
Vol +	Vol +		