Original		Replacement	
	Standby		Power
	Open/Close	ZOOM	Eject
1	1	1	1
2	2	2	2
3	3	3	3
CD	CD	A	Red
RADIO	Radio	SEARCH TV/R	TV/R
AUX	AUX	C	Yellow
USB	USB	D	Blue
DIGITAL	Digital	HOME SMART	Smart
NET	NET	APP MEDIA	Media
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9

Original		Replacement	
	0	0	0
OPTION	Option	SETTINGS OPT	Options
	Play/Pause	PLAY MODE	Play
	Stop		Stop
HOME	Home	SHIFT + HOME SMART	Shift + Smart
RETURN	Return	RETURN BACK	Back
NOW PLAYING	Now Playing	DISPLAY INFO	Info
VOLUME +	Vol +	VOL +	Vol +
VOLUME -	Vol -	VOL -	Vol -
ENTER	Enter	OK	Ok
	Up		Up
	Down		Down
	>>I		>>I
	I <<		I <<
MUTE	Mute	MUTE	Mute
DISPLAY	Display	SHIFT + DISPLAY INFO	Shift + Info
REPEAT	Repeat	REPEAT TEXT	Text

Original	Replacement	Original	Replacement
Shuffle	Dual		
Sleep	Sleep		
Dimer	Subt		
Timer	Shift + AV		
Memory	AV		
<< Tuning	<<		
Tuning >>	>>		
< Preset	Shift + Left		
Preset >	Shift + Right		