Original		Replacement	
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
	Power		Power
DVD	DVD	NETFLIX SEARCH	Red / Netflix / Search
TUN	TUN	APP REPEAT	Green / APP / Repeat
V-1 VIDEO	V1	Prime Video RANDOM	Blue / Prime Video / Random
VIDEO V-2	V2	SHIFT + Prime Video RANDOM	Shift + Blue / Prime
A-1 AUDIO	A1	YouTube REPEAT A-B	Yellow / YouTube / Repeat
AUDIO A-2	A2	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
1 MIDNIGHT	1	TV 1	1
2 P.BASS	2	DVD 2	2
3 FUNCTION	3	CD-STB 3	3
4 FL DIMMER	4	VIDEO 4	4
5 SLEEP	5	TAPE 5	5
6 TIMER/CLOCK ADJ	6	TUNER 6	6
7 DD / DTS	7	AUX - HDD 7	7
8 TEST TONE	8	USB 8	8
9 CH SELECT	9	BLUETOOTH 9	9

Original		Replacement	
>10 SOUND CONTROL	>10	-/-- GUIDE EPG	Guide / EPG / -/--
0/10 DSP	0/10	HDMI - SAT 0	0
C ENTER/DISC DISP	C	CLEAR EXIT CANCEL	Exit / Cancel / Clear
+ TV VOL	Tv Vol +	SHIFT + VOL +	Shift + Vol +
TV VOL −	Tv Vol -	SHIFT + VOL −	Shift + Vol -
FQ+	Up/FQ+		Up
FQ+	Up/FQ+	TUNE+	>> / Tune+
ST−	Left/ST-		Left
ST−	Left/ST-	PRESET-	I<< / Preset-
ST+	Right/ST+		Right
ST+	Right/ST+	PRESET+	>>I / Preset+
FQ−	Down/FQ-		Down
FQ−	Down/FQ-	TUNE-	<< / Tune-
BAND	Band	MEDIA DISPLAY	Display / Media
STATION MEMORY	Station Memory	LIST SMART	Smart / List
MONO	Mono	LANG I/II AUDIO	Audio / Lang I/II
1 MIDNIGHT	1 Tv	SHIFT + TV 1	Shift + 1

Original	Replacement
2 Tv	Shift + 2
3 Tv	Shift + 3
4 Tv	Shift + 4
5 Tv	Shift + 5
6 Tv	Shift + 6
7 Tv	Shift + 7
8 Tv	Shift + 8
9 Tv	Shift + 9
>10 Tv	Shift + Guide / EPG / -/--
0/10 Tv	Shift + 0
C Tv	Shift + Exit / Cancel / Clear
Power Tv	Shift + Power
Up Tv	Shift + Up
Left Tv	Shift + Left
Enter Tv	Shift + OK
Right Tv	Shift + Right
Down Tv	Shift + Down

Original	Replacement
Menu Tv	Shift + Menu /
Stop Tv	Shift + Stop /
Play Tv	Shift + Play /
Pause Tv	Shift + Pause / Step /
Rec Tv	Shift + Rec / Rec Mode
I << Tv	Shift + I << / Preset-
>>I Tv	Shift + >>I / Preset+
CH- Tv	Shift + CH- /
CH+ Tv	Shift + CH+ /
<< Tv	Shift + << /
>> Tv	Shift + >> /
PGM Tv	Shift + D. Menu / Top Menu
RDM Tv	Shift + Subtitle / EQ
Disp Tv	Shift + Display / Media
Last Memory Tv	Shift + Back / Return

Original		Replacement		Original		Replacement	
SOURCE	Source	RDS AV INPUT	AV / Input / RDS	5 SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
	Power		Power	6 TIMER/CLOCK ADJ	6	TUNER 6	6
DVD	DVD	APP REPEAT	Green / APP / Repeat	6 TIMER/CLOCK ADJ	Time/Clock ADJ	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
TUN	TUN	NETFLIX SEARCH	Red / Netflix / Search	7 DD / DTS	7	AUX - HDD 7	7
V-1 VIDEO	V1	Prime Video RANDOM	Blue / Prime Video / Random	7 DD / DTS	[I]/DTS	FORMAT PICTURE	Picture / Format
VIDEO V-2	V2	SHIFT + Prime Video RANDOM	Shift + Blue / Prime	8 TEST TONE	8	USB 8	8
A-1 AUDIO	A1	YouTube REPEAT A-B	Yellow / YouTube / Repeat	8 TEST TONE	Test Tone	GOTO TEXT	Text / Goto
AUDIO A-2	A2	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /	9 CH SELECT	9	BLUETOOTH 9	9
1 MIDNIGHT	1	TV 1	1	9 CH SELECT	CH Select	SHIFT + LIST SMART	Shift + Smart / List
1 MIDNIGHT	Midnight	SIZE ZOOM	Zoom / Size	>10 SOUND CONTROL	>10	-/-- GUIDE EPG	Guide / EPG / -/--
2 P.BASS	2	DVD 2	2	>10 SOUND CONTROL	Sound Control	TITLE SOUND	Sound / Title
2 P.BASS	P.Bass	SURROUND	Eject / Surround	0/10 DSP	0/10	HDMI - SAT 0	0
3 FUNCTION	3	CD - STB 3	3	0/10 DSP	DSP	OPT-TOOLS SETUP	Setup / OPT /
3 FUNCTION	Function	LIST SMART	Smart / List	C ENTER/DISC DISP	C	PC FAV MARKER	Fav / Marker / PC
4 FL DIMMER	4	VIDEO 4	4	C ENTER/DISC DISP	Enter/Disc / DSI	SHIFT + OK	Shift + OK
4 FL DIMMER	FL Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer	TV CHANNEL	TV CH+	SHIFT + CH PAGE	Shift + CH+ /
5 SLEEP	5	TAPE 5	5	+ TV VOL	Tv Vol +	SHIFT + VOL	Shift + Vol +

Original	Replacement
System	Vol +
TV CH-	Shift + CH- /
Tv Vol -	Shift + Vol -
System	Vol -
Tv Input	Shift + AV / Input / RDS
Power Tv	Shift + Power
Mute	Mute / Dimmer
Up/FQ+	Up
Left/ST-	Left
Enter	OK
Right/ST+	Right
Down/FQ-	Down
Exit	Exit / Cancel / Clear
Menu	Menu / Home
Stop	Stop / Hold
Play	Play / Slow
Pause	Pause / Step / Freeze

Original	Replacement
Return	Back / Return
I<</Page-	I<< / Preset-
>>I/Page+	>>I / Preset+
<I/CH-	CH- / Page-
I>/CH+	CH+ / Page+
<<	<< / Tune-
>>	>> / Tune+
Top Menu	D.Menu / Top
PGM	TV/Radio /
Subtitle	Subtitle / EQ
RDM	Shift + Display / Media
Audio	Audio / Lang I/II
Disp	Display / Media
Last Memory	Shift + Back / Return
Angle	Info / Angle
Repeat	Shift + Green / APP /
A-B	Shift + Yellow / YouTube / Repeat

Original		Replacement	
SOURCE	Source	RDS / AV / INPUT	AV / Input / RDS
	Power		Power
DVD	DVD	APP / REPEAT	Green / APP / Repeat
TUN	TUN	NETFLIX / SEARCH	Red / Netflix / Search
V-1 / VIDEO	V1	Prime Video / RANDOM	Blue / Prime Video / Random
VIDEO / V-2	V2	SHIFT + Prime Video / RANDOM	Shift + Blue / Prime
A-1 / AUDIO	A1	YouTube / REPEAT A-B	Yellow / YouTube / Repeat
AUDIO / A-2	A2	SHIFT + NETFLIX / SEARCH	Shift + Red / Netflix /
1 / MIDNIGHT	1	TV 1	1
2 / P.BASS	2	DVD 2	2
3 / FUNCTION	3	CD-STB 3	3
4 / FL DIMMER	4	VIDEO 4	4
5 / SLEEP	5	TAPE 5	5
6 / TIMER/CLOCK ADJ	6	TUNER 6	6
7 / DD / DTS	7	AUX-HDD 7	7
8 / TEST TONE	8	USB 8	8
9 / CH SELECT	9	BLUETOOTH 9	9

Original		Replacement	
0/10 / DSP	0/10	HDMI-SAT 0	0
C / ENTER/DISC DISP	C	PC / FAV MARKER	Fav / Marker / PC
	Up / Pause		Up
ST−	Left / <<		Left
ENTER	Enter / Play	SLOW	Play / Slow
ST+	Right / >>	TUNE+	>> / Tune+
	Down / Stop	HOLD	Stop / Hold
BAND	Down / Stop		Down
STATION MEMORY	Enter / Play	OK	OK
MONO	Up / Pause	STEP-FREEZE	Pause / Step / Freeze
CH−	<I / CH- / I<<	CH PAGE −	CH- / Page-
CH+	II>/ CH+/ >>I	CH PAGE +	CH+ / Page+
	Left / <<	TUNE-	<< / Tune-
GUIDE	Right / >>		Right
1 / MIDNIGHT	1 V2	SHIFT + TV 1	Shift + 1
2 / P.BASS	2 V2	SHIFT + DVD 2	Shift + 2
3 / FUNCTION	3 V2	SHIFT + CD-STB 3	Shift + 3

Original	Replacement	Original	Replacement
4 V2	SHIFT + VIDEO 4	Shift + 4	
5 V2	SHIFT + TAPE 5	Shift + 5	
6 V2	SHIFT + TUNER 6	Shift + 6	
7 V2	SHIFT + AUX - HDD 7	Shift + 7	
8 V2	SHIFT + USB 8	Shift + 8	
9 V2	SHIFT + BLUETOOTH 9	Shift + 9	
0/10 V2	SHIFT + HDMI - SAT 0	Shift + 0	
TV Channel +	SHIFT + CH PAGE +	Shift + CH+ /	
TV Channel - V2	SHIFT + CH PAGE -	Shift + CH- /	
Up / Pause V2	SHIFT + STEP - FREEZE	Shift + Pause / Step /	
Left / << V2	SHIFT + TUNE-	Shift + << /	
Right / >> V2	SHIFT + TUNE+	Shift + >> /	
Down/ Stop V2	SHIFT + HOLD	Shift + Stop /	
Down/ Stop V2	SHIFT + ▼	Shift + Down	
Up / Pause V2	SHIFT + ▲	Shift + Up	
Left / << V2	SHIFT + ◀	Shift + Left	
Right / >> V2	SHIFT + ▶	Shift + Right	

Original		Replacement	
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
	Power		Power
DVD	DVD	APP REPEAT	Green / APP / Repeat
TUN	TUN	NETFLIX SEARCH	Red / Netflix / Search
V-1 VIDEO	V1	Prime Video RANDOM	Blue / Prime Video / Random
VIDEO V-2	V2	SHIFT + Prime Video RANDOM	Shift + Blue / Prime
A-1 AUDIO	A1	YouTube REPEAT A-B	Yellow / YouTube / Repeat
AUDIO A-2	A2	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
1 MIDNIGHT	1	TV 1	1
2 P.BASS	2	DVD 2	2
3 FUNCTION	3	CD-STB 3	3
4 FL DIMMER	4	VIDEO 4	4
5 SLEEP	5	TAPE 5	5
6 TIMER/CLOCK ADJ	6	TUNER 6	6
7 DD / DTS	7	AUX - HDD 7	7
8 TEST TONE	8	USB 8	8
9 CH SELECT	9	BLUETOOTH 9	9

Original		Replacement	
>10 SOUND CONTROL	>10	-/-- GUIDE EPG	Guide / EPG / -/--
0/10 DSP	0/10	HDMI - SAT 0	0
C ENTER/DISC DISP	C	PC FAV MARKER	Fav / Marker / PC
	Up/Pause		Up
ST-	Left/<<	TUNE-	<< / Tune-
ENTER	Enter/Play	OK	OK
ST+	Right/>>	TUNE+	>> / Tune+
	Down/Stop	HOLD	Stop / Hold
BAND	Down/Stop		Down
STATION MEMORY	Enter/Play	SLOW	Play / Slow
MONO	Up/Pause	STEP - FREEZE	Pause / Step / Freeze
PAGE -	I<<	PRESET-	I<< / Preset-
PAGE +	>>I	PRESET+	>>I / Preset+
	Left/<<		Left
GUIDE	Right/>>		Right
TOP MENU PGM	PGM/Top Menu	PROGRAM TV/ RADIO	TV/Radio /
SUBTITLE RDM	Subtitle/RDM	EQ SUBTITLE	Subtitle / EQ

Original	Replacement
Audio/Disp	Display / Media
Repeat	Shift + Green / APP /
1 A2	Shift + 1
2 A2	Shift + 2
3 A2	Shift + 3
4 A2	Shift + 4
5 A2	Shift + 5
6 A2	Shift + 6
7 A2	Shift + 7
8 A2	Shift + 8
9 A2	Shift + 9
>10 A2	Shift + Guide / EPG / -/--
0/10 A2	Shift + 0
C A2	Shift + Fav / Marker / PC
Up/Pause A2	Shift + Pause / Step /
Left/<< A2	Shift + << /
Enter/Play A2	Shift + Play / Slow

Original	Replacement
Right/>> A2	Shift + >> /
Down/Stop A2	Shift + Down
Down/Stop A2	Shift + Stop /
Enter/Play A2	Shift + OK
Up/Pause A2	Shift + Up
I<< A2	Shift + I<< / Preset-
>>I A2	Shift + >>I / Preset+
Left/<< A2	Shift + Left
Right/>> A2	Shift + Right
PGM/Top Menu	Shift + TV/Radio / Program
RDM/Subtitle A2	Shift + Subtitle / EQ
Audio Disp A2	Shift + Display / Media
Repeat A2	Shift + Yellow / YouTube /