Original		Replacement	
	Power		Power
	Audio Source		Red
	Play		Play
	Pause		Pause
	Radio		TV/R
	USB		Yellow
	MP3 Link		Blue
	Disc		Smart
	Audio		Dual
	Options		Options
	Menu/Back		Menu
	[i]/Info		Info
	Stop		Stop
	Mute		Mute
	>I		>>I
	I<		I<<
	Surround		Format

Original		Replacement	
	Vol +		Vol +
	Vol -		Vol -
	Treble		Ch +
	Bass		Ch -
	Up		Up
	Down		Down
	Right/>>		Right
	Left/<<		Left
	OK		Ok
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8

Original		Replacement	
9	9	9	9
0	0	0	0
SUBTITLE	Subtitle	AD SUBT	Subt
AUDIO SYNC	Audio Sync	APP MEDIA	Media
REPEAT PROGRAM	Repeat / Program	PROG SLEEP	Sleep
ZOOM	Zoom	ZOOM ⏏	Eject
REPEAT A-B	A-B/ Repeat	REPEAT TEXT	Text
SOUND	Sound	SHIFT + SOUND DUAL	Shift + Dual
▲	Up Radio	SHIFT + ▲	Shift + Up
▼	Down Radio	SHIFT + ▼	Shift + Down
▶ ▶▶	Right / >> Radio	SHIFT + ▶	Shift + Right
◀◀ ◀	Left / << Radio	SHIFT + ◀	Shift + Left
OK	OK Radio	SHIFT + OK	Shift + Ok
▶I	>I Radio	≫	>>
I◀	I< Radio	≪	<<
1	1 Radio	SHIFT + 1	Shift + 1
2	2 Radio	SHIFT + 2	Shift + 2

Original		Replacement	
3	3 Radio	SHIFT + 3	Shift + 3
4	4 Radio	SHIFT + 4	Shift + 4
5	5 Radio	SHIFT + 5	Shift + 5
6	6 Radio	SHIFT + 6	Shift + 6
7	7 Radio	SHIFT + 7	Shift + 7
8	8 Radio	SHIFT + 8	Shift + 8
9	9 Radio	SHIFT + 9	Shift + 9
0	0 Radio	SHIFT + 0	Shift + 0