Original		Replacement	
	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
i	i	DISPLAY INFO	Info
	Back	RETURN BACK	Back
	[Q]	SEARCH TV/R	TV/R
	↔/ [<>]	PICTURE FORMAT	Format
	Camera	ECO 3D	3D
	Mute	MUTE	Mute

Original		Replacement	
	Up		Up
	Down		Down
	Left		Left
	Right		Right
OK	OK	OK	Ok
TV-G Title	Title/TV-G	DISC NAV LIST	List
TXT	((·))/TXT	REPEAT TEXT	Text
	Stop		Stop
	[/]	HOME SMART	Smart
Jog	Pause/Jog		Pause
	Play	PLAY MODE	Play
	>I		>>I
	I <		I <<
	<<		<<
	>>		>>
	Audio	SOUND DUAL	Dual
	[_]/Picture	AD SUBT	Subt

Original		Replacement	
	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
[Q]	[Q]	SEARCH TV/R	TV/R
↔/[<>]	↔/[<>]	PICTURE FORMAT	Format
	Camera	ECO 3D	3D
	Mute	MUTE	Mute
	Back	RETURN BACK	Back
i	i	DISPLAY INFO	Info

Original		Replacement	
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
TXT	((·))/TTX	REPEAT TEXT	Text
TV-G Title	Title/TV-G	DISC NAV LIST	List
	[/]	HOME SMART	Smart
Jog	Pause/Jog		Pause
	Stop		Stop
	Play	PLAY MODE	Play
	I<		I<<
	>I		>>I
	<<		<<
	>>		>>
	Audio	SOUND DUAL	Dual
	[_]/Picture	AD SUBT	Subt