Original		Replacement	
	Power		Power
	Red/Sound↑		Red / Netflix / Search
	Red/Sound↑		Sound / Title
	Green/Picture/↓		Green / APP / Repeat
	Green/Picture/↓		Picture / Format
	Yellow/Feature		Yellow / YouTube / Repeat
	Blue/Install		Blue / Prime Video / Random
	[≡]		Text / Goto
	[≡0]		Play / Slow
	[≡+]		Stop / Hold
	[≡x]/[· ·]		Pause / Step / Freeze
	[/≡]/[*]		Rec / Rec Mode
	[+]([≡♦]/Wide		Zoom / Size
	[≡?]/PC		Fav / Marker / PC
	[≡i]/Guide		Guide / EPG / -/--
	1		1
	2		2

Original		Replacement	
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	P<P		Display / Media
	0		0
	-/--		Shift + Guide / EPG / -/--
	Vol -		Vol -
	Vol +		Vol +
	Mute		Mute / Dimmer
	P-		CH- / Page-
	P+		CH+ / Page+
	[i]/Info		Info / Angle
	TV/DTV		TV/Radio / Program

Original	Replacement	Original	Replacement
AV	AV / Input / RDS		
I-II	Audio / Lang I/II		
PP	Back / Return		
Up	Up		
Left	Left		
OK/Select	OK		
Right	Right		
M	Menu / Home		
Down	Down		