Original		Replacement	
	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
	Recall	RETURN BACK	Back / Return
0	0	HDMI - SAT 0	0
	Source	RDS AV INPUT	AV / Input / RDS
+	Vol +	+ VOL	Vol +
CONTENT MENU A/D	A/D/Content Menu	LIST SMART	Smart / List
P	P+	+ CH PAGE	CH+ / Page+
−	Vol -	VOL −	Vol -

Original		Replacement	
	Mute	DIMMER MUTE	Mute / Dimmer
P	P-	CH PAGE −	CH- / Page-
DVD MENU MENU	Menu/DVD	HOME MENU	Menu / Home
RETURN EXIT	Exit/Return	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
TOP MENU GUIDE	Guide/Top	-/-- GUIDE EPG	Guide / EPG / -/--
	Down		Down
SET UP TV/FAV RADIO	Tv/FAV/Radio/Set	PROGRAM TV/ RADIO	TV/Radio /
SET UP TV/FAV RADIO	Tv/FAV/Radio/Set	PC FAV MARKER	Fav / Marker / PC
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
	[<>]	FORMAT PICTURE	Picture / Format

Original		Replacement		Original	Replacement
	↤[/]↦	MEDIA DISPLAY	Display / Media		
	[i+] / [≡i]	ANGLE INFO	Info / Angle		
AUDIO TEXT	Text	GOTO TEXT	Text / Goto		
AUDIO TEXT	Audio	LANG I/II AUDIO	Audio / Lang I/II		
SUBTITLE ⏏	Subtitle	EQ SUBTITLE	Subtitle / EQ		
SUBTITLE ⏏	Eject	SURROUND ⏏	Eject / Surround		
CD1/II ■	O) I / II	SHIFT + LANG I/II AUDIO	Shift + Audio / Lang I/II		
CD1/II ■	Stop	HOLD ■	Stop / Hold		
▶	Play/ [≡o]	SLOW ▶	Play / Slow		
II/II▶	II / II >/ [▼]	STEP-FREEZE II	Pause / Step / Freeze		
I◀◀	I <</ [≡?]	PRESET- I◀◀	I << / Preset-		
◀◀	<</ [≡+]	TUNE- ◀◀	<< / Tune-		
▶▶	>>/ [≡♦]	TUNE+ ▶▶	>> / Tune+		
▶▶I	>>I / [O] / [≡X]	PRESET+ ▶▶I	>>I / Preset+		

Original		Replacement	
Power	Power	Power	Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
Source		AV / Input / RDS	
Vol +		Vol +	
Vol -		Vol -	
Mute		Mute / Dimmer	
Menu/DVD		Menu / Home	
Exit/Return		Back / Return	

Original		Replacement	
Up		Up	
Left		Left	
OK		OK	
Right		Right	
Guide/Top		D.Menu / Top	
Down		Down	
Tv/FAV/Radio/Set		Setup / OPT /	
[<>]		Picture / Format	
←[/]→		Display / Media	
[i+]/[≡i]		Info / Angle	
Text		Text / Goto	
Audio		Audio / Lang I/II	
Subtitle		Subtitle / EQ	
Eject		Eject / Surround	
O)I/II		Shift + Audio / Lang I/II	
Stop		Stop / Hold	
Play/[≡o]		Play / Slow	

Original		Replacement		Original	Replacement
	I I / I I >/ [▼]	STEP-FREEZE	Pause / Step / Freeze		
	I <</ [≡?]	PRESET-	I << / Preset-		
	<</ [≡+]	TUNE-	<< / Tune-		
	>>/ [≡♦]	TUNE+	>> / Tune+		
	>>I / [O] / [≡X]	PRESET+	>>I / Preset+		

Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	Recall		Back / Return
	0		0
	Source		AV / Input / RDS
	Vol +		Vol +
	A/D / Content		Smart / List
	P+		CH+ / Page+
	Vol -		Vol -

Original		Replacement	
	Mute		Mute / Dimmer
	P-		CH- / Page-
	Menu/DVD		Menu / Home
	Exit/Return		Shift + Back / Return
	Exit/Return		Exit / Cancel / Clear
	Up		Up
	Left		Left
	OK		OK
	Right		Right
	Guide/Top		D.Menu / Top
	Down		Down
	Tv/FAV/Radio/Set		TV/Radio /
	Tv/FAV/Radio/Set		Setup / OPT /
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random

Original		Replacement		Original	Replacement
	[<>]	FORMAT PICTURE	Picture / Format		
	←[/]→	MEDIA DISPLAY	Display / Media		
	[i+] / [≡i]	ANGLE INFO	Info / Angle		
AUDIO TEXT	Text	GOTO TEXT	Text / Goto		
AUDIO TEXT	Audio	LANG I/II AUDIO	Audio / Lang I/II		
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ		
SUBTITLE	Eject	SURROUND	Eject / Surround		
CD1/II	O) I / II	SHIFT + LANG I/II AUDIO	Shift + Audio / Lang I/II		
CD1/II	Stop	HOLD	Stop / Hold		
	Play/ [≡o]	SLOW	Play / Slow		
	II / II >/ [▼]	STEP-FREEZE	Pause / Step / Freeze		
	I <</ [≡?]	PRESET-	I << / Preset-		
	<</ [≡+]	TUNE-	<< / Tune-		
	>>/ [≡♦]	TUNE+	>> / Tune+		
	>>I / [O] / [≡X]	PRESET+	>>I / Preset+		