Original		Replacement	
Power		Power	
Mute		MUTE	Mute
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
JUMP	Jump	RETURN BACK	Back
-/--	-/--	SHIFT + -/-- GUIDE	Shift + Guide
S.MODE	S. Mode	SHIFT + SOUND DUAL	Shift + Dual
I-II	I-II	SOUND DUAL	Dual
P.MODE	P. Mode	PICTURE FORMAT	Format

Original		Replacement	
GUIDE	Guide	-/-- GUIDE	Guide
EXIT	Exit	CLEAR EXIT	Exit
	Up		Up
	Left		Left
OK	OK	OK	Ok
	Right		Right
	Down		Down
INPUT	Input	TIMER AV	AV
MENU	Menu	TOP MENU MENU	Menu
FAV.CH	Fav. CH	FAV PRE-CH	Pre Ch
VOL. +	Vol. +	VOL +	Vol +
VOL. -	Vol. -	VOL -	Vol -
CH. +	CH. +	CH +	Ch +
CH. -	CH. -	CH -	Ch -
REC	Rec	REC MODE	Rec
DTV/ RADIO	DTV / Radio	SEARCH TV/R	TV/R
SLEEP	Sleep	PROG SLEEP	Sleep

Original		Replacement		Original		Replacement	
SUBTITLE	Subtitle	AD SUBT	Subt	⏭	>>|	⏭	>>|
P.SIZE	P. Size	ZOOM ⏏	Eject	⏮	|<<	⏮	|<<
SUBPAGE	Subpage	SHIFT +	Shift + Subt	⏩	>>	⏩	>>
	Red	A	Red				
	Green	B	Green				
	Yellow	C	Yellow				
	Blue	D	Blue				
	[≡i]	HOME SMART	Smart				
	[≡?]	APP MEDIA	Media				
	[≡↕]	ECO 3D	3D				
	[≡□]	SHIFT + ■	Shift + Stop				
	[≡] / [/≡]	REPEAT TEXT	Text				
■	Stop	■	Stop				
TIMESHIFT ⏯	Play/Pause / Timeshift	PLAY MODE ▶	Play				
TIMESHIFT ⏯	Play/Pause / Timeshift	⏸	Pause				
INFO	Info	DISPLAY INFO	Info				
⏮	|<<	⏮	|<<				