Original		Replacement		Original		Replacement	
ON	On		Power	MUTE	Mute	DIMMER MUTE	Mute / Dimmer
OFF	Off	SHIFT +	Shift + Power	VOL	Vol +	VOL +	Vol +
MAGICNET	Magicnet	FORMAT PICTURE	Picture / Format		Vol -	VOL -	Vol -
MDC	MDC	LANG I/II AUDIO	Audio / Lang I/II	CH/P	CH+	CH PAGE +	CH+ / Page+
LOCK	Lock	RETURN BACK	Back / Return		CH-	CH PAGE -	CH- / Page-
.QZ 1	1	TV 1	1	SOURCE	Source	RDS AV INPUT	AV / Input / RDS
ABC 2	2	DVD 2	2	MENU	Menu	HOME MENU	Menu / Home
DEF 3	3	CD-STB 3	3	TTX/MIX	TTX/MIX	GOTO TEXT	Text / Goto
GHI 4	4	VIDEO 4	4	INFO	[=?]/Info	ANGLE INFO	Info / Angle
JKL 5	5	TAPE 5	5	EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
MNO 6	6	TUNER 6	6		Up		Up
PRS 7	7	AUX-HDD 7	7		Down		Down
TUV 8	8	USB 8	8		Right		Right
WXY 9	9	BLUETOOTH 9	9		Left		Left
SYMBOL 0	0	HDMI-SAT 0	0	ENTER	Enter	OK	OK
DEL -/-- +100	+100/DEL-/--	-/-- GUIDE EPG	Guide / EPG / -/--	AUTO	Red/Auto	NETFLIX SEARCH	Red / Netflix / Search
ENTER/PRE-CH	[=o]/Enter/Pre-C	PC FAV MARKER	Fav / Marker / PC	P.MODE M/B	Green/M/B/P.Mod	APP REPEAT	Green / APP / Repeat

Original		Replacement		Original	Replacement
S.MODE	Yellow/Sound/S. M	YouTube / REPEAT A-B	Yellow / YouTube / Repeat		
STILL	Blue/Still	Prime Video / RANDOM	Blue / Prime Video / Random		
FM RADIO	FM Radio	PROGRAM TV/RADIO	TV/Radio /		
P.SIZE	P.Size	SIZE ZOOM	Zoom / Size		
SRS	(O)/SRS	TIMER SLEEP	Sleep / Timer		
DUAL/MTS	I/II/Dual MTS	TITLE SOUND	Sound / Title		
PIP	[=+]/PIP	TOP MENU D.MENU	D.Menu / Top		
SOURCE	[=♦]/Source	SHIFT + RDS AV INPUT	Shift + AV / Input / RDS		
SWAP	Swap	SURROUND	Eject / Surround		
SIZE	[=x]/Size	SHIFT + SIZE ZOOM	Shift + Zoom /		
REW	<<	TUNE-	<< / Tune-		
STOP	Stop	HOLD	Stop / Hold		
PLAY/PAUSE	Play/Pause	SLOW	Play / Slow		
FF	>>	TUNE+	>> / Tune+		