Original	Replacement	Original	Replacement
Open / Close	Eject / Surround	6	6
Power	Power	Angle	Info / Angle
Mute	Mute / Dimmer	7	7
System	Menu / Home	8	8
Go To	Text / Goto	9	9
L/R	D.Menu / Top	Digest	Sleep / Timer
Program	TV/Radio /	0	0
Repeat	Green / APP / Repeat	10+	Guide / EPG / -/--
Rep A-B	Yellow / YouTube / Repeat	Clear	Exit / Cancel / Clear
Random	Blue / Prime Video / Random	I<< SKip	I<< / Preset-
Audio	Audio / Lang I/II	Skip >>I	>>I / Preset+
1	1	<< Scan	<< / Tune-
2	2	Scan >>	>> / Tune+
3	3	Play	Play / Slow
Subtitle	Subtitle / EQ	Pause	Pause / Step / Freeze
4	4	Stop	Stop / Hold
5	5	Title	Sound / Title

Original		Replacement		Original	Replacement
PBC	PBC	FORMAT PICTURE	Picture / Format		
Up	Up	Up	Up		
Left	Left	Left	Left		
SELECT	Select	OK	OK		
Right	Right	Right	Right		
OSD	OSD	MEDIA DISPLAY	Display / Media		
Down	Down	Down	Down		
RETURN	Return	RETURN BACK	Back / Return		
ZOOM	Zoom	SIZE ZOOM	Zoom / Size		
SLOW	Slow	SHIFT + SLOW	Shift + Play /		
STEP	Step	SHIFT + STEP-FREEZE	Shift + Pause / Step /		
RESUME	Resume	REC MODE	Rec / Rec Mode		
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /		
FUNCTION	Function	LIST SMART	Smart / List		
-	-	VOL -	Vol -		
+	+	+ VOL	Vol +		