Original	Replacement	Original	Replacement
Power	Power	Right	Right
Mute	Mute / Dimmer	Down	Down
Play	Play / Slow	Vol +	Vol +
Stop	Stop / Hold	[-O-] / Active Control	Smart / List
Rec	Rec / Rec Mode	P+	CH+ / Page+
<<	<< / Tune-	Vol -	Vol -
>>	>> / Tune+	P-	CH- / Page-
[<>]	Picture / Format	1	1
>I<	D.Menu / Top	2	2
[1I2]	Setup / OPT /	3	3
[≡]	Text / Goto	4	4
Source	AV / Input / RDS	5	5
Menu	Menu / Home	6	6
Up	Up	7	7
[i+]	Info / Angle	8	8
Left	Left	9	9
OK	OK	Guide	Guide / EPG / -/--

Original	Replacement
0	0
P<P	Fav / Marker / PC
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
Power AMP	Shift + Power
Mute AMP	Shift + Mute / Dimmer
<< AMP	Shift + << /
>> AMP	Shift + >> /
[≡] AMP	Shift + Text /
Menu AMP	Shift + Menu /
Up AMP	Shift + Up
Left AMP	Shift + Left
OK AMP	Shift + OK
Right AMP	Shift + Right
Down AMP	Shift + Down

Original	Replacement
Vol + AMP	Shift + Vol +
P+ AMP	Shift + CH+ /
Vol - AMP	Shift + Vol -
P- AMP	Shift + CH- /
1 AMP	Shift + 1
2 AMP	Shift + 2
3 AMP	Shift + 3
4 AMP	Shift + 4
5 AMP	Shift + 5
6 AMP	Shift + 6
7 AMP	Shift + 7
8 AMP	Shift + 8
9 AMP	Shift + 9
Guide AMP	Shift + Guide / EPG / -/--
0 AMP	Shift + 0
P<P AMP	Shift + Fav / Marker / PC

Original	Replacement	Original	Replacement
Power	Power	P-	CH- / Page-
Guide	Guide / EPG / -/--	1	1
Source	AV / Input / RDS	2	2
>I<	D.Menu / Top	3	3
[1I2]	Setup / OPT /	4	4
[i+]	Info / Angle	5	5
Up	Up	6	6
Left	Left	7	7
OK	OK	8	8
Right	Right	9	9
Down	Down	0	0
[≡]	Text / Goto	P<P	Fav / Marker / PC
Menu	Menu / Home	<<	<< / Tune-
Vol +	Vol +	Stop	Stop / Hold
Mute	Mute / Dimmer	Play	Play / Slow
P+	CH+ / Page+	>>	>> / Tune+
Vol -	Vol -	[<>]	Picture / Format

Original	Replacement	Original	Replacement
[-O-]/Active Control	Smart / List		

Original		Replacement	
	Power		Power
	Mute		Mute / Dimmer
	Play		Play / Slow
	Stop		Stop / Hold
	Rec		Rec / Rec Mode
	<<		<< / Tune-
	>>		>> / Tune+
	[<>]		Picture / Format
	>I<		D.Menu / Top
	[1I2]		Setup / OPT /
	Source		AV / Input / RDS
	Menu		Menu / Home
	Up		Up
	[i+]		Info / Angle
	Left		Left
OK	OK	OK	OK
	Right		Right

Original		Replacement	
	Down		Down
	Vol +		Vol +
	[-O-]/Active Control		Smart / List
	P+		CH+ / Page+
	Vol -		Vol -
	P-		CH- / Page-
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
P<P	P<P		Fav / Marker / PC

Original	Replacement	Original	Replacement
Red	Red / Netflix / Search	Right VCR	Shift + Right
Green	Green / APP / Repeat	Down VCR	Shift + Down
Yellow	Yellow / YouTube / Repeat	P+ VCR	Shift + CH+ /
Blue	Blue / Prime Video / Random	P- VCR	Shift + CH- /
Power VCR	Shift + Power	1 VCR	Shift + 1
Play VCR	Shift + Play /	2 VCR	Shift + 2
Stop VCR	Shift + Stop /	3 VCR	Shift + 3
Rec VCR	Shift + Rec / Rec Mode	4 VCR	Shift + 4
<< VCR	Shift + << /	5 VCR	Shift + 5
>> VCR	Shift + >> /	6 VCR	Shift + 6
>I < VCR	Shift + D.Menu / Top Menu	7 VCR	Shift + 7
Source VCR	Shift + AV / Input / RDS	8 VCR	Shift + 8
Menu VCR	Shift + Menu /	9 VCR	Shift + 9
Up VCR	Shift + Up	0 VCR	Shift + 0
[i+] VCR	Shift + Info / Angle	P<P VCR	Shift + Fav / Marker / PC
Left VCR	Shift + Left		
OK VCR	Shift + OK		

Original	Replacement	Original	Replacement
Power	Power	5	5
Guide	Guide / EPG / -/--	6	6
>I<	D.Menu / Top	7	7
[i+]	Info / Angle	8	8
Up	Up	9	9
Left	Left	0	0
Right	Right	P<P	Fav / Marker / PC
Down	Down	<<	<< / Tune-
Vol +	Vol +	Stop	Stop / Hold
Mute	Mute / Dimmer	Play	Play / Slow
P+	CH+ / Page+	>>	>> / Tune+
Vol -	Vol -		
P-	CH- / Page-		
1	1		
2	2		
3	3		
4	4		