Mandis shop

RB-DTA120



Original		Replacement	
⏻/ON	Standby/On	⏻	Power
FUNCTION	Function	HOME MENU	Menu / Home
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
SNOOZE	Snooze	OK	OK
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
CLOCK/TIMER	Clock/Timer	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
TIME ON/OFF	Time On/Off	FORMAT PICTURE	Picture / Format
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
MEMORY	Memory	LIST SMART	Smart / List
■	Stop	HOLD ■	Stop / Hold

Original		Replacement	
▶/II	Play	SLOW ▶	Play / Slow
▶/II	Pause	STEP - FREEZE II	Pause / Step / Freeze
0	0	HDMI - SAT 0	0
REPEAT/ FM MODE	Repeat/FM	APP REPEAT	Green / APP / Repeat
— TUNI ⏮	I<</Tuning-	PRESET- ⏮	I<< / Preset-
JNING + ⏭	>>I/Tuning+	PRESET+ ⏭	>>I / Preset+
BAND	Band	Prime Video RANDOM	Blue / Prime Video / Random
TUNER PRESET	Tuner Preset	PROGRAM TV/ RADIO	TV/Radio /
SOUND	Sound	TITLE SOUND	Sound / Title
BASS	Bass	LANG I/II AUDIO	Audio / Lang I/II
VOLL —	Volume-	VOL —	Vol-
LUME +	Volume+	+ VOL	Vol+



https://remotecontrols.dk/en/Sanyo/1068912-91458-replacement-remote-control-for-Sanyo-RB-DTA120.html