| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Power | Power | Blue / Title | Blue |
| HDMI Control | Smart | 1 | 1 |
| Rec | Rec | 2 | 2 |
| Play | Play | 3 | 3 |
| Pause | Pause | 4 | 4 |
| Stop | Stop | 5 | 5 |
| I<< | I<< | 6 | 6 |
| << | << | 7 | 7 |
| >> | >> | 8 | 8 |
| >>I | >>I | 9 | 9 |
| Screen | Format | 0 | 0 |
| Lang | Dual | Text | Text |
| Subtitle | Subt | Swap | Pre Ch |
| PIP / World | 3D | Up | Up |
| Red / Zoom | Red | Right | Right |
| Green / Repeat | Green | Down | Down |
| Yellow / Root | Yellow | Left | Left |

| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| OK | OK | OK | Ok | | | | |
| P/CH + | P/CH + | CH + | Ch + | | | | |
| P/CH - | P/CH - | CH - | Ch - | | | | |
| Mute | Mute | MUTE | Mute | | | | |
| Vol + | Vol + | VOL + | Vol + | | | | |
| Vol - | Vol - | VOL - | Vol - | | | | |
| MENU | Menu | TOP MENU MENU | Menu | | | | |
| SOURCE | Source | TIMER AV | AV | | | | |
| RETURN | Return | RETURN BACK | Back | | | | |
| EPG | EPG | -/-- GUIDE | Guide | | | | |
| INFO | Info | DISPLAY INFO | Info | | | | |
| SLEEP | Sleep | PROG SLEEP | Sleep | | | | |
| FAV | FAV | SHIFT + FAV PRE-CH | Shift + Pre Ch | | | | |
| | Angle / Media | APP MEDIA | Media | | | | |
| SEARCH MODE | Search Mode | SEARCH TV/R | TV/R | | | | |
| DISPLAY | Display | SHIFT + DISPLAY INFO | Shift + Info | | | | |
| PRESETS | Presets | DISC NAV LIST | List | | | | |