Original		Replacement	
	Power Tuner		Power
	Mute	MUTE	Mute
1	1 Tuner	1	1
2	2 Tuner	2	2
3	3 Tuner	3	3
4	4 Tuner	4	4
5	5 Tuner	5	5
6	6 Tuner	6	6
7	7 Tuner	7	7
8	8 Tuner	8	8
9	9 Tuner	9	9
0	0 Tuner	0	0
CINEMA GO	Cinema Go	GUIDE	Guide
	Vol +	VOL +	Vol +
	Vol -	VOL -	Vol -
	Play Tuner/Phono/Cabl	PLAY MODE	Play
	Stop Tuner/Phono/Cabl e Box		Stop

Original		Replacement	
LOUDNESS	Loudness	AD SUBT	Subt
SUBW. ON/OFF	Subw. On/Off	HOME SMART	Smart
VIRTUAL MODE	Mode/Virtual	SETTINGS OPT	Options
NIGHT	Night	ECO 3D	3D
SURROUND ON/OFF	Surround On/Off	APP MEDIA	Media
REAR +	Channel/Rear+	+ CH	Ch +
- CHANNEL	Channel/Rear-	CH -	Ch -
SURROUND MODE	Surround Mode	SEARCH TV/R	TV/R
TEST TONE	Test Tone	CLEAR EXIT	Exit
+ SUB WOOFER	Sub woofer+	B	Green
SUB WOOFER -	Sub Woofer-	A	Red
	Right Tuner		Right
	Up Tuner		Up
	Down Tuner		Down
	Left Tuner		Left
OK	OK Tuner	OK	Ok
GUIDE MENU	Menu / Guide	TOP MENU MENU	Menu

Tuner

Original		Replacement	
NEWS/TA	i / News/ TA	DISPLAY INFO	I nf o
CHANNE	I < Channel / Track	I <<	
L/TRACK	Channel / Track >I Tuner	>>I	
FR.D.	Pause/ FR. D.	Pause	
TUNER	Tuner	SHIFT + HOME SMART	Shi f t + Smart
PHONO	Phono	SHIFT + APP MEDIA	Shi f t + Medi a
	Power Phono	SHIFT +	Shi f t + Power

Original	Replacement

Original		Replacement	
	Power Tv		Power
	TV		Blue
	Mute Tv		Mute
	1 Tv		1
	2 Tv		2
	3 Tv		3
	4 Tv		4
	5 Tv		5
	6 Tv		6
	7 Tv		7
	8 Tv		8
	9 Tv		9
	0 Tv		0
	Menu/Guide Tv		Menu
	OK Tv		Ok
	Up Tv		Up
	Down Tv		Down

Original		Replacement	
	Right Tv		Right
	Left Tv		Left
	Vol + Tv/CD		Vol +
	Vol - Tv/CD		Vol -
	Play Tv		Play
	Stop Tv		Stop
	i/News/TA Tv		Info
	I< Channel/Track		I<<
	Channel/Track >I		>>I
	Power CD		Shift + Power
	CD		Yellow
	Mute CD		Shift + Mute
	1 CD		Shift + 1
	2 CD		Shift + 2
	3 CD		Shift + 3
	4 CD		Shift + 4
	5 CD		Shift + 5

Original		Replacement		Original	Replacement
6	6 CD	SHIFT + 6	Shift + 6		
7	7 CD	SHIFT + 7	Shift + 7		
8	8 CD	SHIFT + 8	Shift + 8		
9	9 CD	SHIFT + 9	Shift + 9		
0	0 CD	SHIFT + 0	Shift + 0		
	Up CD	SHIFT +	Shift + Up		
	Down CD	SHIFT +	Shift + Down		
	Right CD	SHIFT +	Shift + Right		
	Left CD	SHIFT +	Shift + Left		
i NEWS/TA	i / News/ TA CD	SHIFT + DISPLAY INFO	Shift + Info		
	Stop CD	SHIFT +	Shift + Stop		
	Play CD	SHIFT + PLAY MODE	Shift + Play		
CHANNE	I < CD	<<	<<		
L/TRACK	>I CD	>>	>>		
FR.D.	Pause/ FR. D. CD	II	Pause		
CANCEL	: >/ Cancel CD	CLEAR EXIT	Exit		
DVD DISC	Disc/ DVD CD	HOME SMART	Smart		

Original		Replacement	
	Power SAT		Power
SAT	SAT	C	Yellow
1	1 SAT	1	1
2	2 SAT	2	2
3	3 SAT	3	3
4	4 SAT	4	4
5	5 SAT	5	5
6	6 SAT	6	6
7	7 SAT	7	7
8	8 SAT	8	8
9	9 SAT	9	9
0	0 SAT	0	0
MUTE	Mute SAT	MUTE	Mute
	Vol + SAT/DVD	+ VOL	Vol +
	Vol - SAT/DVD	VOL −	Vol -
	Play SAT	PLAY MODE	Play
	Stop SAT		Stop

Original		Replacement	
i NEWS/TA	i/News/TA SAT	DISPLAY INFO	Info
GUIDE MENU	Menu/Guide	TOP MENU MENU	Menu
OK	OK SAT	OK	Ok
	Up SAT		Up
	Down SAT		Down
	Right SAT		Right
	Left SAT		Left
CHANNE	I< Channel/Track SAT		I<<
L/TRACK	Channel/Track >I SAT		>>I
CANCEL	:>/Cancel SAT	CLEAR EXIT	Exit
INDEX T·C	T·C/Index SAT	RETURN BACK	Back
	Power DVD	SHIFT +	Shift + Power
DVD	DVD	D	Blue
1	1 DVD	SHIFT + 1	Shift + 1
2	2 DVD	SHIFT + 2	Shift + 2
3	3 DVD	SHIFT + 3	Shift + 3
4	4 DVD	SHIFT + 4	Shift + 4

Original		Replacement	
5 DVD		SHIFT + 5	Shift + 5
6 DVD		SHIFT + 6	Shift + 6
7 DVD		SHIFT + 7	Shift + 7
8 DVD		SHIFT + 8	Shift + 8
9 DVD		SHIFT + 9	Shift + 9
0 DVD		SHIFT + 0	Shift + 0
GUIDE MENU	Menu/Guide	SHIFT + TOP MENU	Shift + Menu
OK DVD		SHIFT + OK	Shift + Ok
Up DVD		SHIFT + ▲	Shift + Up
Down DVD		SHIFT + ▼	Shift + Down
Right DVD		SHIFT + ▶	Shift + Right
Left DVD		SHIFT + ◀	Shift + Left
Play DVD		SHIFT + PLAY MODE	Shift + Play
Stop DVD		SHIFT + ■	Shift + Stop
i / News/TA DVD		SHIFT + DISPLAY INFO	Shift + Info
CHANNE	I< Channel / Track DVD	<<	<<
L/TRACK	Channel / Track >I DVD	>>	>>

Original		Replacement	
DVD DISC	Disc DVD	HOME SMART	Smart
REC AUDIO	Audio DVD	SOUND DUAL	Dual
CANCEL	:>/Cancel DVD	SHIFT + CLEAR EXIT	Shift + Exit
FR.D.	Pause/FR.D.	II	Pause
INDEX T·C	T·C/Index DVD	SHIFT + RETURN BACK	Shift + Back

Original		Replacement	
	Power VCR		Power
VCR	VCR	C	Yellow
MUTE	Mute VCR	MUTE	Mute
1	1 VCR	1	1
2	2 VCR	2	2
3	3 VCR	3	3
4	4 VCR	4	4
5	5 VCR	5	5
6	6 VCR	6	6
7	7 VCR	7	7
8	8 VCR	8	8
9	9 VCR	9	9
0	0 VCR	0	0
GUIDE MENU	Menu/Guide	TOP MENU MENU	Menu
	Up VCR		Up
OK	OK VCR	OK	Ok
	Down VCR		Down

Original		Replacement	
	Right VCR		Right
	Left VCR		Left
	Vol + VCR	+ VOL	Vol +
	Vol - VCR	VOL −	Vol -
	Play VCR	PLAY MODE	Play
	Stop VCR		Stop
CHANNE	I< Channel / Track VCR		I<<
L/TRACK	Channel / Track >I VCR		>>I
REC AUDIO	Rec VCR	REC MODE	Rec
CANCEL	:>/Cancel VCR	CLEAR EXIT	Exit
F.R.D.	Pause/F.R.D VCR		Pause
INDEX T·C	T·C/Index VCR	RETURN BACK	Back
	Power	SHIFT +	Shift + Power
CDR/TAPE	CDR/Tape	D	Blue
1	1 CDR/Tape	SHIFT + 1	Shift + 1
2	2 CDR/Tape	SHIFT + 2	Shift + 2
3	3 CDR/Tape	SHIFT + 3	Shift + 3

Original		Replacement	
4	4 CDR/Tape	SHIFT + 4	Shift + 4
5	5 CDR/Tape	SHIFT + 5	Shift + 5
6	6 CDR/Tape	SHIFT + 6	Shift + 6
7	7 CDR/Tape	SHIFT + 7	Shift + 7
8	8 CDR/Tape	SHIFT + 8	Shift + 8
9	9 CDR/Tape	SHIFT + 9	Shift + 9
0	0 CDR/Tape	SHIFT + 0	Shift + 0
	Up CDR/Tape	SHIFT +	Shift + Up
	Down CDR/Tape	SHIFT +	Shift + Down
	Right CDR/Tape	SHIFT +	Shift + Right
	Left CDR/Tape	SHIFT +	Shift + Left
NEWS/TA	i/News/TA	DISPLAY INFO	Info
CHANNEL	I< Channel/Track CDR/Tape	SHIFT +	Shift + I<<
L/TRACK	Channel/Track >I CDR/Tape	SHIFT +	Shift + >>I
REC AUDIO	Rec CDR/Tape	SHIFT + REC MODE	Shift + Rec
CANCEL	:>/Cancel	SHIFT + CLEAR EXIT	Shift + Exit
F.R.D.	Pause/F.R.D. CDR/Tape	SHIFT +	Shift + Pause

Original		Replacement	
DVD DISC	Disc CDR/Tape	HOME SMART	Smart