Original		Replacement	
	Power		Power
1	1	1	1
2abc	2	2	2
3def	3	3	3
4 ghi	4	4	4
5 jkl	5	5	5
6mno	6	6	6
7pqrs	7	7	7
8 tuv	8	8	8
9 wxyz	9	9	9
0	0	0	0
EXIT	Exit	CLEAR EXIT	Exit
TV/ RADIO	Tv/ Radio	SEARCH TV/R	TV/ R
SYNC MENU	Sync Menu	TOP MENU MENU	Menu
	Source	TIMER AV	AV
NETFLIX	Netflix	APP MEDIA	Media
DIGITAL/ ANALOG	Digital/ Analog	HOME SMART	Smart

Original		Replacement	
ACTION MENU	Action Menu	SHIFT + TOP MENU MENU	Shift + Menu
HOME	Home	PROG SLEEP	Sleep
GUIDE	Guide	GUIDE	Guide
BACK	Back	RETURN BACK	Back
TV	TV	SETTINGS OPT	Options
	Recall	FAV PRE-CH	Pre Ch
HELP	Help	ECO 3D	3D
	[≡]	REPEAT TEXT	Text
	[i+]/[?]	DISPLAY INFO	Info
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
	OK	OK	Ok
	Up		Up
	Down		Down
	Right		Right

Original		Replacement		Original		Replacement	
	Left		Left	DISCOVER	Discover	E-MANUAL D.MENU	D. Menu
	Vol +	VOL +	Vol +				
	Vol -	VOL −	Vol -				
PROG +	Prog+	CH +	Ch +				
PROG −	Prog-	CH −	Ch -				
AUDIO	Audio	SOUND DUAL	Dual				
	[...]	AD SUBT	Subt				
TITLE LIST	Title List	PICTURE FORMAT	Format				
▶	Play	PLAY MODE ▶	Play				
⏸	Pause	⏸	Pause				
■	Stop	■	Stop				
▶▶	>>	▶▶	>>				
◀◀	<<	◀◀	<<				
⏮	I <<	⏮	I <<				
⏭	>>I	⏭	>>I				
REC	Rec	REC MODE	Rec				
	Mute	MUTE	Mute				