Original		Replacement		Original		Replacement	
	Power		Power	PROG	Prog	PROGRAM TV/RADIO	TV/Radio /
	Open/Close	SURROUND	Eject / Surround	SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
1	1	TV 1	1		Up		Up
2	2	DVD 2	2	DVD/ESB	DVD/USB	RDS AV INPUT	AV / Input / RDS
3	3	CD - STB 3	3	DVD/ESB	DVD/USB	SHIFT + DVD 2	Shift + 2
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ	DVD/ESB	DVD/USB	SHIFT + USB 8	Shift + 8
4	4	VIDEO 4	4		Left		Left
5	5	TAPE 5	5	ENTER	Enter	OK	OK
6	6	TUNER 6	6		Right		Right
LANGUAGE	Language	LANG I/II AUDIO	Audio / Lang I/II	MENU	Menu	HOME MENU	Menu / Home
7	7	AUX - HDD 7	7		Down		Down
8	8	USB 8	8	MUTE	Mute	DIMMER MUTE	Mute / Dimmer
9	9	BLUETOOTH 9	9	REV	<</Rev	TUNE-	<< / Tune-
OSD	OSD	MEDIA DISPLAY	Display / Media	SEARCH	Search	NETFLIX SEARCH	Red / Netflix / Search
0/10	0/10	HDMI - SAT 0	0	REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
10+	10+	-/-- GUIDE EPG	Guide / EPG / -/--	PREV	I<</Prev	PRESET-	I<< / Preset-
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear	FWD	>>/Fwd	TUNE+	>> / Tune+

Original		Replacement	
STOP	Stop	HOLD	Stop / Hold
PLAY/PAUSE	Play	SLOW	Play / Slow
PLAY/PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
NEXT	>>I / Next	PRESET+	>>I / Preset+
VOLUME	Vol -	VOL	Vol -
VOLUME	Vol +	VOL	Vol +
TITLE	Title	TITLE SOUND	Sound / Title
RETURN	Return	RETURN BACK	Back / Return
V.MODE	V-Mode	FORMAT PICTURE	Picture / Format
SLOW	Slow	SHIFT + SLOW	Shift + Play /
A-B	A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat
RAN	RAN	GOTO TEXT	Text / Goto
N/P	N/P	CH PAGE	CH+ / Page+
L/R	L/R	CH PAGE	CH- / Page-
ANGLE	Angle	ANGLE INFO	Info / Angle
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
RESUME	Resume	LIST SMART	Smart / List

Original		Replacement	
STEP	Remain	TOP MENU D.MENU	D.Menu / Top