Mandis shop

Samsung AH59-02546B

Original		Rechange	
POWER	Power		Power
TV POWER	Tv Power	SHIFT +	Shift + Power
TV VOL +	Tv Vol +	SHIFT + VOL +	Shift + Vol +
TV VOL -	Tv Vol -	SHIFT + VOL -	Shift + Vol -
TV CH	Tv CH+	CH +	Ch +
TV CH	Tv CH-	CH -	Ch -
TV SOURCE	Tv Source	SEARCH TV/R	TV/R
SOURCE	Source	TIMER AV	AV
REPEAT	Repeat	REPEAT TEXT	Text
Anynet*	Anynet*	APP MEDIA	Media
SoundShare	SoundShare	SETTINGS OPT	Options
SPEAKER	Speaker	GUIDE	Guide
AUTO POWER	Auto Power	PROG SLEEP	Sleep
TV MUTE	Tv Mute	SHIFT + MUTE	Shift + Mute
TV INFO	Tv Info	DISPLAY INFO	Info
TV PRE-CH	Tv Pre-CH	FAV PRE-CH	Pre Ch
TV EXIT	Tv Exit	CLEAR EXIT	Exit

Original		Rechange	
VOL +	Vol +	VOL +	Vol +
S/W LEVEL	>S/W Level		Right
MUTE	Mute	MUTE	Mute
VOL -	Vol -	VOL -	Vol -
S/W LEVEL	< S/W Level		Left
SOUND EFFECT	Sound Effect	SOUND DUAL	Dual
DRC	DRC	PICTURE FORMAT	Format
SMART VOLUME	Smart Volume	HOME SMART	Smart
3D SOUND PLUS	3D Sound Plus	ECO 3D	3D
AUDIO SYNC +	Audio Sync+		Up
AUDIO SYNC -	Audio Sync-		Down
	Stop		Stop
	I<<		I<<
	Play	PLAY MODE	Play
	Pause		Pause
	>>I		>>I

https://remotes.fr/Samsung-1365660-telecommande-remplacement-pour-Samsung-AH59-02546B.htm